

**RC 390**

ART. NO. 3214955EN





Congratulations on your decision to purchase a KTM motorcycle. You are now the owner of a state-of-the-art, sporty motorcycle that you will continue to enjoy for a long time if you maintain it properly. We wish you good and safe riding at all times!

Enter the serial numbers of your vehicle below.

Vehicle identification number (📖 p. 15)	Dealer's stamp
Engine number (📖 p. 15)	
Key number (📖 p. 16)	

The Owner's Manual contained the latest information for this model series at the time of publication. However, minor differences due to further developments in design cannot be ruled out completely.

All specifications contained herein are non-binding. KTM Sportmotorcycle GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from figures and descriptions, misprints, and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2024 KTM Sportmotorcycle GmbH, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

KTM applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.

Issued by: TÜV Management Service

REG.NO. 12 100 6061

KTM Sportmotorcycle GmbH  
Stallhofnerstraße 3  
5230 Mattighofen, Austria

This document is valid for the following models:

RC 390 US (F5375X1, F5375X2)

RC 390 US (F5375X1L, F5375X2L)



















3214955en

28.02.2024

# TABLE OF CONTENTS

1	MEANS OF REPRESENTATION .....	5	6.5	Switches on the right side of the handlebar.....	19
1.1	Symbols used .....	5	6.5.1	Emergency OFF switch .....	19
1.2	Formats used.....	5	6.5.2	Start button .....	19
2	SAFETY ADVICE.....	6	6.6	Ignition and steering lock.....	19
2.1	Use definition – intended use.....	6	6.7	Locking the steering.....	19
2.2	Misuse.....	6	6.8	Unlocking the steering.....	20
2.3	Safety advice.....	6	6.9	Opening fuel tank filler cap.....	20
2.4	Degrees of risk and symbols.....	6	6.10	Closing the fuel tank filler cap.....	21
2.5	Overview of labels .....	7	6.11	Seat lock.....	21
2.6	Reporting safety defects .....	8	6.12	Tool set.....	22
2.7	Noise emission warranty .....	9	6.13	Supporting strap .....	22
2.8	Operating noise warning .....	9	6.14	Passenger foot pegs .....	22
2.9	Manufacturer warranty for the exhaust monitoring system.....	9	6.15	Shift lever .....	22
2.10	Consumer rights.....	9	6.16	Foot brake lever .....	23
2.11	Tampering warning.....	10	6.17	Side stand.....	23
2.12	Safe operation .....	10	7	ERGONOMICS .....	24
2.13	Protective clothing .....	10	7.1	Adjusting the basic position of the hand brake lever .....	24
2.14	Work rules.....	11	7.2	Adjusting the basic position of the clutch lever .....	24
2.15	Environment.....	11	7.3	Adjusting the shift lever.....	24
2.16	Owner's Manual .....	11	8	COMBINATION INSTRUMENT .....	26
3	IMPORTANT NOTES.....	12	8.1	Combination instrument .....	26
3.1	Manufacturer warranty, implied warranty.....	12	8.2	Activation and test .....	26
3.2	Fuel, auxiliary substances.....	12	8.3	Day-night mode .....	26
3.3	Spare parts, technical accessories .....	12	8.4	Warnings.....	27
3.4	Service .....	12	8.5	Indicator lamps.....	27
3.5	Figures .....	12	8.6	Display .....	28
3.6	Customer service.....	12	8.7	MTC display .....	29
4	VIEW OF VEHICLE .....	13	8.8	ABS display.....	29
4.1	View of vehicle, front left (example) ...	13	8.9	Engine speed.....	29
4.2	View of vehicle, rear right (example).....	14	8.10	Shift warning light .....	30
5	SERIAL NUMBERS .....	15	8.11	Speed .....	30
5.1	Vehicle identification number.....	15	8.12	ODO display .....	30
5.2	Type label .....	15	8.13	Coolant temperature indicator .....	31
5.3	Engine number .....	15	8.14	Fuel level display .....	31
5.4	Key number.....	16	8.15	Time.....	32
6	CONTROLS.....	17	8.16	Favourites display .....	32
6.1	Clutch lever.....	17	8.17	Quick Selector 1 display .....	32
6.2	Hand brake lever.....	17	8.18	Quick Selector 2 display .....	32
6.3	Throttle grip .....	17	8.19	Menu .....	33
6.4	Switches on the left side of the handlebar.....	17	8.19.1	KTM MY RIDE (optional) .....	33
6.4.1	Combination switch.....	17	8.19.2	Trips/Data .....	33
6.4.2	Light switch .....	18	8.19.3	Motorcycle .....	34
6.4.3	Menu buttons.....	18	8.19.4	Settings .....	34
6.4.4	Turn signal switch.....	18	8.19.5	Pairing (optional) .....	34
6.4.5	Horn button .....	18	8.19.6	Phone (optional) .....	35
			8.19.7	Headset (optional) .....	36
			8.19.8	Audio (optional).....	37
			8.19.9	Telephony (optional) .....	38
			8.19.10	General Info .....	38

8.19.11	Trip 1 .....	38	13.2	Removing the rear of the motorcycle from the lifting gear .....	61
8.19.12	Trip 2 .....	39	13.3	Lifting the motorcycle with the front lifting gear .....	61
8.19.13	Warning .....	39	13.4	Taking the motorcycle off the front lifting gear .....	62
8.19.14	ABS.....	39	13.5	Cleaning the dust boots of the fork legs .....	62
8.19.15	MTC+MSR (optional).....	40	13.6	Removing the front rider's seat.....	63
8.19.16	Quick Shift+ (optional).....	41	13.7	Mounting the front rider's seat.....	63
8.19.17	Favourites .....	41	13.8	Checking for chain dirt accumulation.....	64
8.19.18	Quick Selector 1 .....	41	13.9	Cleaning the chain .....	64
8.19.19	Quick Selector 2 .....	41	13.10	Checking the chain tension.....	65
8.19.20	Bluetooth (optional) .....	42	13.11	Adjusting the chain tension.....	65
8.19.21	Display Theme.....	42	13.12	Checking the chain, rear sprocket, and engine sprocket .....	66
8.19.22	Shift Light .....	43	13.13	Removing the fuel tank cover  .....	67
8.19.23	Setting the time and date .....	43	13.14	Mounting the fuel tank cover.....	68
8.19.24	Distance .....	44	13.15	Removing the left side cover  .....	69
8.19.25	Fuel Cons.....	44	13.16	Installing the left side cover  .....	69
8.19.26	Language .....	45	13.17	Removing the right side cover  .....	70
8.19.27	Service .....	45	13.18	Installing the right side cover  .....	70
8.19.28	Extra Functions .....	45	13.19	Removing the front fender .....	71
9	PREPARING FOR USE.....	46	13.20	Installing the front fender .....	71
9.1	Advice on preparing for first use .....	46	14	BRAKE SYSTEM .....	72
9.2	Running in the engine .....	47	14.1	Anti-lock braking system (ABS) .....	72
9.3	Loading the vehicle .....	47	14.2	Checking the brake discs .....	73
10	RIDING INSTRUCTIONS.....	48	14.3	Checking the front brake fluid level ...	73
10.1	Checks and maintenance measures when preparing for use .....	48	14.4	Adding front brake fluid  .....	74
10.2	Starting.....	48	14.5	Checking that the brake linings of the front brake are secured .....	75
10.3	Starting off.....	49	14.6	Checking the rear brake fluid level.....	76
10.4	quickshifter + (optional) .....	50	14.7	Adding rear brake fluid  .....	76
10.5	Shifting, riding .....	50	14.8	Checking that the brake linings of the rear brake are secured.....	78
10.6	Applying the brakes.....	52	14.9	Checking the free travel of foot brake lever .....	78
10.7	Stopping, parking.....	53	14.10	Adjusting the free travel of the foot brake lever  .....	79
10.8	Transport .....	54	15	WHEELS, TIRES .....	80
10.9	Towing in the event of a breakdown ...	55	15.1	Removing the front wheel  .....	80
10.10	Refueling .....	55	15.2	Installing the front wheel  .....	80
11	SERVICE SCHEDULE .....	57	15.3	Removing the rear wheel  .....	81
11.1	Additional information.....	57	15.4	Installing the rear wheel  .....	82
11.2	Service work.....	57	15.5	Checking the rear hub damping rubber pieces  .....	83
12	TUNING THE CHASSIS .....	59	15.6	Checking the tire condition .....	84
12.1	Adjusting the compression damping of the fork .....	59	15.7	Checking tire pressure .....	85
12.2	Adjusting the rebound damping of the fork.....	59	16	ELECTRICAL SYSTEM .....	86
12.3	Adjusting the spring preload of the shock absorber  .....	60	16.1	Removing the 12-V battery  .....	86
12.4	Adjusting the rebound damping of the shock absorber.....	60	16.2	Installing the 12-V battery  .....	86
13	SERVICE WORK ON THE CHASSIS.....	61			
13.1	Raising the motorcycle with rear lifting gear .....	61			








# TABLE OF CONTENTS

16.3	Charging the 12-V battery	87	23.9	Chassis tightening torques	116
16.4	Changing the main fuse	89	24	DECLARATIONS OF CONFORMITY	120
16.5	Changing the ABS fuses	89	24.1	Declarations of conformity	120
16.6	Changing the fuses of individual electrical power consumers	91	25	SUBSTANCES	121
16.7	Checking the headlight setting	92	26	AUXILIARY SUBSTANCES	123
16.8	Adjusting the headlight range	92	27	STANDARDS	124
16.9	Diagnostics connector	93	28	INDEX OF SPECIAL TERMS	125
16.10	ACC1 front	93	29	LIST OF ABBREVIATIONS	126
16.11	ACC1 and ACC2 rear	93	30	LIST OF SYMBOLS	127
17	COOLING SYSTEM	94	30.1	Red symbols	127
17.1	Cooling system	94	30.2	Yellow and orange symbols	127
17.2	Checking the coolant level in the compensating tank	94	30.3	Green and blue symbols	127
17.3	Checking the antifreeze and coolant level	95	INDEX		128
17.4	Draining the coolant	96			
17.5	Filling/bleeding the cooling system	97			
17.6	Changing the coolant	98			
18	TUNING THE ENGINE	101			
18.1	Checking the clutch lever play	101			
18.2	Adjusting play in the clutch lever	101			
19	SERVICE WORK ON THE ENGINE	102			
19.1	Checking the engine oil level	102			
19.2	Changing the engine oil and oil filter, cleaning the oil screens	102			
19.3	Adding engine oil	104			
20	CLEANING, CARE	105			
20.1	Cleaning the motorcycle	105			
20.2	Checks and maintenance steps for winter operation	106			
21	STORAGE	107			
21.1	Storage	107			
21.2	Preparing for use after storage	108			
22	TROUBLESHOOTING	109			
23	TECHNICAL SPECIFICATIONS	111			
23.1	Engine	111			
23.2	Engine tightening torques	112			
23.3	Capacities	114			
23.3.1	Engine oil	114			
23.3.2	Coolant	114			
23.3.3	Fuel	114			
23.4	Chassis	114			
23.5	Electrical system	115			
23.6	Tires	115			
23.7	Fork	115			
23.8	Shock absorber	116			

## 1.1 Symbols used

The meaning of specific symbols is described below.

---

	Indicates an expected reaction (e.g., of a work step or a function).
	Indicates an unexpected reaction (e.g., of a work step or a function).
	Indicates work that requires expert knowledge and technical understanding. In the interest of your own safety, have these jobs performed by an authorized KTM workshop! Your motorcycle will be cared for there to the highest degree by specially trained experts using the special tools required.
	Indicates a page reference (more information is provided on the specified page).
	Indicates information with more details or tips.
	Indicates the result of a testing step.
	Indicates the end of an activity, including potential reworking.

---

## 1.2 Formats used

The typographical formats used in this document are explained below.

---

<b>Proprietary name</b>	Indicates a proprietary name.
<b>Name®</b>	Indicates a protected name.
<b>Brand™</b>	Indicates a brand available on the open market.
<b><u>Underlined terms</u></b>	Refer to technical details of the vehicle or indicate technical terms, which are explained in the glossary.

---

### 2.1 Use definition – intended use

This vehicle has been designed and built to withstand the normal stresses and strains of road use. This vehicle is not suitable for use on race tracks or offroad.



#### Info

This vehicle is only authorized for operation on public roads in its homologated version.

### 2.2 Misuse

The vehicle must only be used as intended.

Dangers can arise for people, property and the environment through use not as intended.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Misuse also includes the use of operating and auxiliary fluids which do not meet the required specification for the respective use.

### 2.3 Safety advice

A number of safety instructions need to be followed to operate the product described safely. Therefore read this instruction and all further instructions included carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



#### Info

Various information and warning labels are attached in prominent locations on the product described. Do not remove any information or warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

### 2.4 Degrees of risk and symbols



#### Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



#### Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



#### Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

#### Note


Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



#### Note

Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.5 Overview of labels



S06194-10

1 Type label for Canada

2 Information on noise emissions

3 Information on emissions control

4 Information on preparations for use

5 Type label for USA

MANUFACTURED BY/FABRIQUÉ PAR:		BAJAJ AUTO LTD. INDIA FOR KTM AG			
GVWR/PNBV: 335 KG		DATE: mm/jj			
V.I.N./N.I.V.: MD2xxxxxxCxxxxxx					
TYPE: MC					
GAWR/PNBE		TIRE/PNEU-DIMENSION-RIM/JANTE		COLD INFL. PRESS. PRESS. DE GONFL. À FROID	
	KG			PSI/LPC	KPA
1st	125	110/70R17	3.00-17	29	200
2nd	210	150/60R17	4.00-17	29	200
THIS VEHICLE CONFORMS TO ALL APPLICABLE STANDARDS PRESCRIBED UNDER THE CANADIAN MOTOR VEHICLE SAFETY REGULATIONS IN EFFECT ON THE DATE OF MANUFACTURE - CE VÉHICULE EST CONFORME À TOUTES LES NORMES QUI LUI SONT APPLICABLES EN VERTU DU RÈGLEMENT SUR LA SÉCURITÉ DES VÉHICULES AUTOMOBILES DU CANADA EN VIGUEUR À LA DATE DE SA FABRICATION					

S05289-01

Type label for Canada

<p>MOTORCYCLE NOISE EMISSION CONTROL INFORMATION                  BAJAJ AUTO LTD. INDIA FOR KTM AG                  THIS 2022 KTM MOTORCYCLE, 938.05.083.000 MEETS EPA NOISE EMISSION REQUIREMENTS OF 80 dBA AT 7100 RPM BY THE FEDERAL TEST PROCEDURE. MODIFICATIONS WHICH CAUSE THIS MOTORCYCLE TO EXCEED FEDERAL NOISE STANDARDS ARE PROHIBITED BY U.S. FEDERAL LAW. SEE OWNER'S MANUAL.</p>	
<p>Motorcycle Type : RC 390</p>	

S05290-01

Information on noise emissions

## 2 SAFETY ADVICE

VEHICLE EMISSION CONTROL INFORMATION	
<b>KTM</b> MANUFACTURER: BAJAJ AUTO LTD. INDIA FOR KTM AG IMPORTER: KTM NORTH AMERICA, INC.	
ENGINE DISPLACEMENT	373 cc ENGINE EXHAUST EMISSION CONTROL SYSTEM:
ENGINE FAMILY	JKTXC.373BAL TWC, TBI, HO2S
EVAPORATIVE FAMILY	JKTXU0014BAL
PERMEATION FAMILY	JKTXPMETALBD MODEL NAME RC 390
THIS VEHICLE CONFORMS WITH US EPA AND CALIFORNIA REGULATIONS APPLICABLE TO 2022 MODEL YEAR NEW MOTORCYCLES AND IS CERTIFIED TO 0.8 G/KM HC+NOX, 12 G/KM CO EXHAUST EMISSION STANDARDS IN CALIFORNIA.	
ENGINE TUNEUP SPECIFICATIONS:	
IGNITION TIMING :	NON ADJUSTABLE
IDLE SPEED :	1700 +/- 50 RPM IN NEUTRAL
IDLE MIXTURE :	NON ADJUSTABLE
VALVE CLEARANCE :	0.10 - 0.15 mm INTAKE 0.15 - 0.20 mm EXHAUST
SPARK PLUG :	BOSCH VR5NEU
SPARK PLUG GAP :	1.0 mm
FUEL :	UNLEADED GASOLINE ONLY - 91 (R+M)/2 OCTANE OR HIGHER
OIL :	SAE 15 W 50

S05291-01

Information on emissions control

**ACHTUNG**

Lesen Sie vor der ersten Inbetriebnahme des Fahrzeuges die gesamte Bedienungsanleitung aufmerksam durch!

**IMPORTANT**

Please read the entire owner's manual carefully before putting the vehicle into operation for the first time.

**ATTENZIONE**

Prima della messa in funzione iniziale del veicolo, leggere con attenzione l'intero manuale d'uso!

**ATTENTION**

Lire attentivement l'ensemble du manuel d'utilisation avant de mettre le véhicule en service!

**ATENCIÓN**

Lea completa y atentamente el manual de instrucciones antes de poner en servicio por primera vez el vehículo!

S00725-01

Information on preparations for use

MFD. BY BAJAJ AUTO LTD. INDIA FOR KTM AG		DATE mm/jj
<b>KTM</b> MOTORCYCLE		
GVWR	740 lbs 335 kg	
GAWR FRONT	276 lbs 125 kg WITH 110/70R17 TIRE, 54H TYPE,	
	3.00-17 RIM, AT 29 psi 2.0 bar COLD	
GAWR REAR	464 lbs 210 kg WITH 150/60R17 TIRE, 66H TYPE,	
	4.00-17 RIM, AT 29 psi 2.0 bar COLD	
THIS VEHICLE CONFORMS TO ALL APPLICABLE U.S. FEDERAL MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE SHOWN ABOVE.		
<b>MD2xxxxxxx Cxxxxxx</b>		

S05288-01

Type label for USA

### 2.6 Reporting safety defects

If you believe that your vehicle has a defect which could cause an accident resulting in injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying KTM North America, Inc.

If the NHTSA receives multiple similar complaints, it may open an investigation. and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or KTM North America, Inc.

You can contact the NHTSA via the toll-free "Auto Safety Hotline" on 1-888-327-4236, visit the [www.nhtsa.dot.gov](http://www.nhtsa.dot.gov) website, or write to: NHTSA Headquarters, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590, USA. You can also obtain other information about motor vehicle safety from the hotline.

## 2.7 Noise emission warranty

KTM warrants that this exhaust system, at the time of sale, meets all applicable U.S. EPA Federal noise standards.

This manufacturer's warranty extends to the first person who purchases this exhaust system for purposes other than resale, and to all subsequent buyers.

Warranty claims should be directed to:

KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (440) 985-3553

[www.ktmusa.com](http://www.ktmusa.com)

KTM Canada, Inc., Customer Support, 8701 Rue Samuel-Hatt, Chambly, QC J3L 6V4, Canada

Phone: (450) 441-4451

[www.ktmcanada.com](http://www.ktmcanada.com)

## 2.8 Operating noise warning

This product should be checked for necessary repair or replacement parts if the motorcycle noise has increased significantly through use. Otherwise, the owner may become subject to penalties under the applicable ordinances.

## 2.9 Manufacturer warranty for the exhaust monitoring system

KTM North America, Inc. guarantees that, at the time of sale, the exhaust monitoring system complies with all the standards of the US Environmental Protection Agency (EPA) and the California Air Resources Board (CARB).

This manufacturer warranty applies in respect of the first owner of the motorcycle and all subsequent owners.

Your exhaust monitoring system may include parts, such as the fuel injection system, ignition, catalytic converter, control units, hoses, connectors and other emission related assemblies, fuel tank, crankcase breather, fuel tank lid for vehicles with fuel evaporation monitoring, oil filler cap, pressure control valve, fuel/vapor separator, canister, ignition coils, ignition wire, capacitors and spark plugs, if a fault occurs before the first scheduled replacement; it may also include the hoses, fittings, and pipes that are used directly in these components.

If the warranty conditions are met, KTM will repair your motorcycle for you free of charge, including diagnosis, parts, and labor.

As the owner of the motorcycle, you are responsible for the required maintenance specified in the Owner's Manual.

Please note that KTM is entitled to reject warranty claims if your motorcycle or a part fails due to misuse, negligence, an accident, participation in racing or similar events, improper maintenance or unauthorized modifications.

### Scope of the manufacturer's warranty

- Five (5) years or 30,000 kilometers (18,641 miles), whichever occurs first.

If you have any questions regarding the manufacturer warranty for the exhaust monitoring system, please address these to:

KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (888) 985-6090

U.S. Environmental Protection Agency, 2000 Traverwood Drive, Ann Arbor, MI 48105, USA

California Air Resources Board, 1001 "I" Street, Sacramento, CA 95814, USA

## 2.10 Consumer rights

Warranty claims must be submitted to an authorized KTM workshop. If you are not satisfied, please contact:

KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (440) 985-3553

[www.ktmusa.com](http://www.ktmusa.com)

KTM Canada, Inc., Customer Support, 8701 Rue Samuel-Hatt, Chambly, QC J3L 6V4, Canada

Phone: (450) 441-4451

[www.ktmcanada.com](http://www.ktmcanada.com)

Different rights may apply, according to national or regional legislation.

### 2.11 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of servicing, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencers, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of parts of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

### 2.12 Safe operation



#### **Danger**

**Danger of accidents** A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



#### **Danger**

**Danger of poisoning** Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



#### **Warning**

**Danger of burns** Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

An appropriate driver's license is needed to ride the vehicle on public roads.

Have malfunctions that impair safety promptly eliminated by an authorized KTM workshop.

Adhere to the information and warning labels on the vehicle.

### 2.13 Protective clothing



#### **Warning**

**Risk of injury** Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

In the interest of your own safety, KTM recommends that you only operate the vehicle while wearing protective clothing.

## 2.14 Work rules

Unless specified otherwise, the ignition must be turned off during all work (models with ignition lock, models with transponder key) or the motor must be at a standstill (models without ignition lock or transponder key). Special tools are necessary for certain tasks. If these special tools are not included in the scope of supply of the vehicle, the special tools can be ordered using the specified article number. Example: bearing puller (15112017000)

Unless otherwise noted, normal conditions apply to all tasks and descriptions.

Ambient temperature	20 °C (68 °F)
Ambient air pressure	1,013 mbar (14.69 psi)
Relative air humidity	60 ± 5 %

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).

In the case of certain screw connections, a thread locker (e.g., **Loctite**®) is required. Observe the manufacturer's instructions.

If a thread locker (e.g. **Precote**®) has already been applied to a new part, do not apply any additional thread locker.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.

Ensure that the work area is clean and clean components before disassembly if necessary. Penetrating dirt can lead to increased wear and consequential damage.

After completing a repair or service work, check the operating safety of the vehicle.

## 2.15 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.

Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized KTM dealer will be glad to advise you.

## 2.16 Owner's Manual

Read this owner's manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and service your motorcycle. This is the only way to find out how best to customize the vehicle for your own use and how you can protect yourself from injury.



### Tip

Store the Owner's Manual on your terminal device, for example, so that you can read it whenever you need to.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized KTM dealer.

The Owner's Manual is an important component of the vehicle. If the vehicle is sold, the Owner's Manual must be downloaded again by the new owner.

The Owner's Manual can be downloaded several times using the QR code or the link on the delivery certificate.

The Owner's Manual is also available for download from your authorized KTM dealer and on the KTM website. A printed copy can also be ordered from your authorized KTM dealer.

International KTM Website: [KTM.COM](http://KTM.COM)

## 3 IMPORTANT NOTES

### 3.1 Manufacturer warranty, implied warranty

The work prescribed in the service schedule must be carried out in an authorized KTM workshop only and confirmed in the electronic proof of service, since otherwise no warranty claims will be recognized. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer warranty.

### 3.2 Fuel, auxiliary substances



#### Note

**Environmental hazard** Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.

Use fuels and auxiliary substances in accordance with the Owner's Manual and specification.

### 3.3 Spare parts, technical accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by KTM and have them installed by an authorized KTM workshop. KTM accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Your authorized KTM dealer will be glad to advise you.

The latest news **KTM PowerParts** on your vehicle can be found on the KTM website.  
International KTM Website: [KTM.COM](http://KTM.COM)

### 3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle in difficult conditions, such as in rain, dusty or sandy environments, high heat or with a heavy payload, can lead to significantly increased wear on components such as the drivetrain, air filter, brake systems or suspension components. It may therefore be necessary to check parts before each journey or to replace parts before the next service interval is reached.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

The relevant mileage or time interval is whichever occurs first.

### 3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

### 3.6 Customer service

Your authorized KTM dealer will be happy to answer any questions you may have on your vehicle and KTM.


A list of authorized KTM dealers can be found on the KTM website.  
International KTM Website: [KTM.COM](http://KTM.COM)

## 4.1 View of vehicle, front left (example)



- ❶ Clutch lever (📖 p. 17)
- ❷ Light switch (📖 p. 18)
- ❷ Horn button (📖 p. 18)
- ❷ Turn signal switch (📖 p. 18)
- ❸ Fuel tank filler cap
- ❹ Seat lock (📖 p. 21)
- ❺ Side stand (📖 p. 23)
- ❻ Shift lever (📖 p. 22)


## 4.2 View of vehicle, rear right (example)



S06193-11


- ❶ Tool set (📖 p. 22)
- ❷ Throttle grip (📖 p. 17)
- ❸ Start button (📖 p. 19)
- ❹ Emergency OFF switch (📖 p. 19)
- ❺ Ignition and steering lock (📖 p. 19)
- ❻ Hand brake lever (📖 p. 17)
- ❼ Level viewer, engine oil
- ❽ Foot brake lever (📖 p. 23)
- ❾ Passenger foot pegs (📖 p. 22)

## 5.1 Vehicle identification number




The vehicle identification number **1** is stamped on the right of the frame behind the steering head.

## 5.2 Type label




The USA type label **1** is located on the right under the passenger seat.




The Canada type label **2** is located on the bottom frame on the left.

## 5.3 Engine number



The engine number **1** is stamped on the left side of the engine under the engine sprocket.

## 5.4 Key number



The key number ① can be found on the **KEYCODECARD**.




### Info

The key number is needed to order a replacement key. Keep the **KEYCODECARD** in a safe place.


If at least one ignition key is still available, a spare key can be produced. If an ignition key is no longer present, the entire lock system must be replaced.

## 6.1 Clutch lever



Clutch lever ❶ is fitted on the handlebar on the left.


## 6.2 Hand brake lever



The hand brake lever ❶ is located on the right side of the handlebar.

The front brake is engaged using the hand brake lever.

## 6.3 Throttle grip




The throttle grip ❶ is fitted on the right side of the handlebar.

## 6.4 Switches on the left side of the handlebar

### 6.4.1 Combination switch


The combination switch is fitted on the left side of the handlebar.



#### Overview of the left combination switch

- ❶ Light switch (🔦 p. 18)
- ❷ Menu buttons (📁 p. 18)
- ❸ Turn signal switch (🚦 p. 18)
- ❹ Horn button (🔊 p. 18)

## 6.4.2 Light switch




Light switch ① is fitted on the left side of the handlebar.

### Possible states

	Low beam on – Light switch in position ①. In this position, the low beam and the tail light are switched on.
	High beam on – Push the light switch to position ②. In this position, the high beam and the tail light are switched on.
	Headlight flasher – Push the light switch into position ③.

## 6.4.3 Menu buttons



The menu buttons are fitted in the middle of the left combination switch.

The menu buttons are used to control the display on the combination instrument.

Button ① is the **UP** button.

Button ② is the **DOWN** button.

Button ③ is the **SET** button.

Button ④ is the **BACK** button.

## 6.4.4 Turn signal switch



Turn signal switch ① is fitted on the left side of the handlebar.

### Possible states

	Turn signal off – Turn signal switch pushed toward the switch housing.
	Left turn signal, on – Turn signal switch pressed to the left. The turn signal switch returns automatically to the central position after use.
	Right turn signal, on – Turn signal switch pressed to the right. The turn signal switch returns automatically to the central position after use.

## 6.4.5 Horn button



Horn button ① is fitted on the left side of the handlebar.

### Possible states

- The horn button ① is in the basic position
- The horn button ① is pressed – The horn is operated in this position.

**6.5 Switches on the right side of the handlebar**

**6.5.1 Emergency OFF switch**



The emergency OFF switch **1** is fitted on the right side of the handlebar.

**Possible states**

	Emergency OFF switch off – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine cannot be started.
	Emergency OFF switch on – This position is required for operation; the ignition circuit is closed.

**6.5.2 Start button**



Start button **1** is fitted on the right side of the handlebar.

**Possible states**

- The start button **1** is in the basic position
- The start button **1** is pressed – In this position, the starter motor is actuated.

**6.6 Ignition and steering lock**



The ignition and steering lock is located in front of the upper triple clamp.

**Possible states**


	Ignition off <b>OFF</b> – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start. The ignition key can be removed.
	Ignition on <b>ON</b> – In this position, the ignition circuit is closed and the engine can be started.
	Steering locked – In this position, the ignition circuit is interrupted and the steering locked. The ignition key can be removed.

**6.7 Locking the steering**

**Note**


**Danger of damage** The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



- Park the vehicle.
- Turn the handlebar all the way to the left.
- Insert the ignition key into the ignition and steering lock, press in, and turn to the left. Remove the ignition key.
- ✓ Steering is no longer possible.

## 6.8 Unlocking the steering



- Insert the ignition key into the ignition and steering lock, press in, and turn to the right. Remove the ignition key.
- ✓ The handlebar can now be moved again.

## 6.9 Opening fuel tank filler cap



### Danger

**Fire hazard** Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



### Warning

**Danger of poisoning** Fuel is harmful to health.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



### Note

**Environmental hazard** Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Lift cover **1** of the fuel tank filler cap and insert the ignition key into the lock.

**Note**


**Danger of damage** The ignition key may break if overloaded.

Damaged ignition keys must be replaced.

- Push down on the fuel tank filler cap to take pressure off the ignition key.
- Turn the ignition key 90° clockwise.
- Lift the fuel tank filler cap.
- Remove the ignition key.



## 6.10 Closing the fuel tank filler cap



**Warning**

**Fire hazard** Fuel is highly flammable and a health hazard.

- Check that the fuel tank filler cap is locked correctly after closing.
- Change your clothing if fuel spills on them.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Close the fuel tank filler cap.
- Turn the ignition key 90° clockwise.
- Push down the fuel tank filler cap and turn the ignition key counterclockwise until the fuel tank filler cap lock engages.
- Remove the ignition key and close the cover.




## 6.11 Seat lock



Seat lock **1** is behind of front rider's seat.


The seat lock can be unlocked using the ignition key.

## 6.12 Tool set




The tool set ❶ is in the storage compartment under the seat.

## 6.13 Supporting strap



The passenger can hold onto the supporting strap ❶ during the trip.

## 6.14 Passenger foot pegs




The passenger foot pegs can be folded up and down.


### Possible states

- Passenger foot pegs folded up – For operation without a passenger.
- Passenger foot pegs folded down – For operation with a passenger.

## 6.15 Shift lever




Shift lever ❶ is mounted on the left side of the engine.




The gear positions can be seen in the photograph.  
The neutral or idle position is between the first and second gears.

## 6.16 Foot brake lever



Foot brake lever ① is located in front of the right footrest.  
The foot brake lever is used to activate the rear brake.

## 6.17 Side stand



The side stand ① is located on the left of the vehicle.  
The side stand is used for parking the motorcycle.


### **i** Info

The side stand must be folded up during motorcycle use.  
The side stand is coupled with the safety starting system;  
follow the riding instructions.

### Possible states

- Side stand folded out – The vehicle can be supported on the side stand. The safety starting system is active.
- Side stand folded in – This position is mandatory when riding the motorcycle. The safety starting system is inactive.


## 7.1 Adjusting the basic position of the hand brake lever



- Adjust the basic position of the hand brake lever to your hand size by turning adjusting wheel **1**.

**i Info**  
Push the hand brake lever forward and turn the adjusting wheel.  
Do not make any adjustments while riding.

## 7.2 Adjusting the basic position of the clutch lever




- Adjust the basic position of the clutch lever to your hand size by turning adjusting wheel **1**.

**i Info**  
Push the clutch lever forward and turn the adjusting wheel.  
Do not make any adjustments while riding.

## 7.3 Adjusting the shift lever

**i Info**  
The adjustment range of the shift lever is limited.



- Loosen nut **1** while holding stud **2**.

**i Info**  
Nut **1** has an LH thread.

- Loosen nut **3** while holding stud **2**.
- Adjust the shift lever by turning shift rod **2**.

Guideline

Shift rod adjustment range <b>A</b>	197 ... 204 mm (7.76 ... 8.03 in)
-------------------------------------	-----------------------------------

**i Info**  
Make equal adjustments on both sides.  
At least five screw threads must be screwed into the seating.

- Check adjusting angle **B**.

Guideline

Adjusting angle <b>B</b> shift rod - bell crank - shift lever	78°
---	-----

- Tighten nut **3** while holding stud **2**.

Guideline

Nut, shift rod	M6	10 Nm (7.4 lbf ft)
----------------	----	--------------------

- Tighten nut ❶ while holding stud ❷.


Guideline

Nut, shift rod	M6LH	10 Nm (7.4 lbf ft)
----------------	------	--------------------

- Check the shift lever to ensure it is functioning properly and can move freely.



## 8.1 Combination instrument



The combination instrument is attached in front of the handlebar. The combination instrument is divided into two function areas.

① indicator lamps (📖 p. 27)

Display ②

## 8.2 Activation and test



### Activation

The combination instrument is activated when the ignition is switched on.


### Info

The brightness of the displays is controlled by an ambient light sensor in the combination instrument.


### Test

The welcome text appears on the display and the indicator lamps are briefly activated for a function check.

## 8.3 Day-night mode



Day mode is shown in a bright color.




Night mode is shown in a dark color.

### Info

The ambient light sensor in the combination instrument detects the brightness of the environment. Depending on the amount of light detected by the ambient light sensor, the display is brightened or dimmed, or switched to the other display mode depending on the setting.

The display mode can be configured in the **Display Theme** menu. Here, you can select automatic day-night mode or permanent night mode.

## 8.4 Warnings



Warnings appear on the top and/or bottom edge of the display; these are marked yellow or red depending on their relevance. Yellow warnings ① indicate malfunctions or information which require prompt intervention or an adjustment to the riding style. Red warnings ② indicate malfunctions or information which require immediate intervention.

### **i** Info

Warnings can be hidden by pressing any button. All the existing warnings are displayed in the **Warning** menu until they are no longer active.

## 8.5 Indicator lamps



The indicator lamps offer additional information about the operating state of the motorcycle. When the ignition is switched on, all indicator lamps light up briefly.

### **i** Info










The malfunction indicator lamp always lights up as long as the engine is not running. If the engine is running and the malfunction indicator lamp lights up, stop (taking care not to endanger yourself or other road users in the process) and contact an authorized KTM workshop.

The oil pressure warning lamp always lights up as long as the engine is not running. If the engine is running and the oil pressure warning lamp lights up, stop immediately (taking care not to endanger yourself or other road users in the process) and switch off the engine.

The ABS warning lamp lights up until a speed of approx. 6 km/h (approx. 4 mph) or more has been reached.

# 8 COMBINATION INSTRUMENT

## Possible states

	The turn signal indicator lamp flashes green simultaneously with the turn signal – The turn signal is switched on.
	The malfunction indicator lamp lights up yellow – The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized KTM workshop.
	The ABS warning lamp lights up yellow – Status or error messages relating to ABS.
	TC indicator lamp lights up yellow – MTC is not enabled or is currently intervening. The TC indicator lamp also lights up if a malfunction is detected. Contact an authorized KTM workshop. The TC indicator lamp flashes if MTC makes an active intervention.
	The idle indicator lamp lights up green – The transmission is in the neutral position.
	The oil pressure warning lamp lights up red – The oil pressure is too low. Stop immediately, taking care not to endanger yourself or other road users in the process, and switch off the engine.
	Alarm system indicator lamp flashes red – Status message on the alarm system (optional).
	The high beam indicator lamp lights up blue – The high beam is switched on.
	The general warning lamp lights up yellow – A note/warning note on operating safety has been detected. This is shown in addition.

## 8.6 Display




S05094-10

- ① Engine speed (📖 p. 29)
- ① Shift warning light (📖 p. 30)
- ① The shift warning light is integrated in the tachometer display.
- ② Gear display

- ③ Unit for the engine speed display
- ④ Speed (📖 p. 30)
- ⑤ Unit for the speedometer
- ⑥ **ODO** display (📖 p. 30)
- ⑦ ABS mode
- ⑧ Coolant temperature indicator (📖 p. 31)
- ⑨ Fuel level display (📖 p. 31)
- ⑩ Ambient temperature display
- ⑪ Time (📖 p. 32)
- ⑫ **SET**  
Only shown when the menu overview is closed.
- ⑬ **Favourites** display (📖 p. 32)


## 8.7 MTC display



The ① area of the display indicates whether **MTC** is switched on or off.


The motorcycle traction control can be switched on or off in the **MTC** submenu.

## 8.8 ABS display




The ABS mode setting is shown in the ① area of the display. The ABS can be configured in the **ABS** submenu.

## 8.9 Engine speed



The speed ① is measured in revolutions per minute.

## 8.10 Shift warning light




The shift warning light is integrated in the tachometer display. The speed for the shift warning light can be set in the **Shift Light** menu. The shift warning light is always active during the running-in time (up to 1000 km / 621 mi). The shift warning light can only be deactivated, and the values for **RPM1** and **RPM2** can only be adjusted after this. In **RPM1** the shift warning light flashes and in **RPM2** it flashes and the color changes.

### **i** Info

After the first service, the shift warning light is deactivated when the engine is warm and in sixth-gear.


Coolant temperature	$\leq 35\text{ }^{\circ}\text{C}$ ( $\leq 95\text{ }^{\circ}\text{F}$ )
<b>ODO</b>	< 1,000 km (< 620 mi)
The shift warning light always flashes at	6,500 rpm
Coolant temperature	$> 35\text{ }^{\circ}\text{C}$ ( $> 95\text{ }^{\circ}\text{F}$ )
<b>ODO</b>	> 1,000 km (> 620 mi)
<b>RPM1</b> shift warning light	flashes
<b>RPM2</b> shift warning light	flashes and changes color

## 8.11 Speed



Speed **1** is shown in kilometers per hour **km/h** or in miles per hour **mph**.

## 8.12 ODO display




The total distance covered **ODO** is shown in area **1** of the display.

### **i** Info

This value is retained, even if the 12-V battery is disconnected from the vehicle or the fuse blows.

### 8.13 Coolant temperature indicator



The coolant temperature indicator consists of bars. The more bars that light up, the hotter the coolant.

#### Note

**Engine failure** Overheating damages the engine.

- If the coolant temperature warning is displayed, stop immediately and take care not to endanger yourself or other traffic participants in the process.
- Allow the engine and cooling system to cool down.
- Check and, if necessary, correct the coolant level on the cooling system while it is in a cooled state.

#### i Info


When all the bars light up, the **ENGINE TEMP HIGH** warning also appears.

If the cooling system overheats, the maximum engine speed is limited.

#### Possible states

- The engine is cold – Up to three bars light up.
- Engine warm – Four to five bars light up.
- Engine hot – Six to eight bars light up.
- Engine very hot – All eight bars light up red.

### 8.14 Fuel level display



The fuel tank capacity is shown in area ① of the display.

The fuel level indicator consists of bars. The more bars are lit, the more fuel is in the fuel tank.

#### i Info

If the fuel level is getting low, the last segment flashes red and the following warning **LOW FUEL** also appears.


The fuel level is displayed with a slight delay to prevent the indicator from constantly moving while riding.

The fuel level display is not updated while the side stand is folded out or the emergency off switch is switched off.

Once the side stand is folded up and the emergency OFF switch is switched on, the fuel level display is next updated after 2 minutes.

The fuel level display flashes if the combination instrument does not receive a signal from the fuel level sensor.

## 8.15 Time




The time is shown in area **1** of the display.

The time is displayed in 24 hour format in all languages except for EN-US. The time is displayed in 12 hour format if the language is set to EN-US.

The time can be configured in the **Clock/Date** menu.

**i Info**  
The time must be reset if the 12-V battery was disconnected from the vehicle or the fuse was removed.

## 8.16 Favourites display




Up to eight items of information are shown in the **Favourites** display.

The **Favourites** indicator can be freely configured in the **Favourites** menu.

**i Info**  
One to four items of information selected are displayed on two lines. Five to eight items of information selected are displayed on a single line.

## 8.17 Quick Selector 1 display




When the menu is closed, **Quick Selector 1** is opened by pressing the **UP** button.

Press the **BACK** button to close **Quick Selector 1**.

**i Info**  
The **Quick Selector 1** can be configured in the **Quick Selector 1** menu. Any information can be selected.

## 8.18 Quick Selector 2 display




When the menu is closed, **Quick Selector 2** is opened by pressing the **DOWN** button.

Press the **BACK** button to close **Quick Selector 2**.

**i Info**  
The **Quick Selector 2** can be configured in the **Quick Selector 2** menu. Any information can be selected.

## 8.19 Menu




### **i** Info

Press the **SET** button **1** in the start screen to open the menu.

Navigate through the menu using the **UP** button **2** or the **DOWN** button **3**.

Press the **BACK** button **4** to close the current menu or the menu overview.

### 8.19.1 KTM MY RIDE (optional)



#### Condition

- The motorcycle is stationary.
- Function **KTM MY RIDE** (optional) activated.
- Function **Bluetooth®** (optional) activated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **KTM MY RIDE** is highlighted. Press the **SET** button to open the menu.

### **i** Info


This function is only available if the vehicle has **Bluetooth®** hardware.

A suitable cellphone or communication system can be paired with the combination instrument via **Bluetooth®** in the **KTM MY RIDE** menu.

### **i** Info

Not every cellphone or communication system is suitable for pairing with the combination instrument. The standard **Bluetooth®** 2.1 must be supported.


### 8.19.2 Trips/Data



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trips/Data** is highlighted. Press the **SET** button to open the menu.

General information can be accessed in **Trips/Data**.


## 8.19.3 Motorcycle



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.

The vehicle riding mode can be configured in **Motorcycle**.

## 8.19.4 Settings




### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.

The combination instrument display can be configured in **Settings**. Settings can be made for units or various values. Several functions can be enabled or disabled. Favorites and quick selections can be configured.

## 8.19.5 Pairing (optional)



### Condition

- The motorcycle is stationary.
- Function **KTM MY RIDE** (optional) activated.
- Function **Bluetooth®** (optional) activated.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **KTM MY RIDE** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Pairing** is highlighted. Press **SET** button to open the menu.

### **i** Info


This function is only available if the vehicle has **Bluetooth®** hardware.

A suitable cellphone or communication system can be paired with the combination instrument via **Bluetooth®** in the **Pairing** menu.

### **i** Info

The **Bluetooth®** function can only be used in conjunction with **KTM MY RIDE** (optional).  
When the **Bluetooth®** function is switched on and the device is connected, the **Bluetooth®** symbol appears in the display of the combination instrument.  
Not every cellphone or communication system is suitable for pairing with the combination instrument.

## 8.19.6 Phone (optional)

**Condition**

- The motorcycle is stationary.
  - Function **KTM MY RIDE** (optional) activated.
  - Function **Bluetooth** (optional) activated.
  - The **Bluetooth**® function should also be activated in the device to be paired.
- Press the **SET** button when the menu is closed.
  - Press the **UP** or **DOWN** button until **KTM MY RIDE** is highlighted. Press the **SET** button to open the menu.
  - Press the **UP** or **DOWN** button until **Pairing** is highlighted. Press **SET** button to open the menu.
  - Press **UP** or **DOWN** button until **Phone** is highlighted. Press the **SET** button to open the menu.

**i Info**

This function is only available if the vehicle has **Bluetooth**® hardware.

A suitable cellphone can be paired with the combination instrument in the **Phone** menu.

Two cellphones can never be paired simultaneously with the combination instrument.

- Press **UP** or **DOWN** button until **Pairing** is highlighted. Press the **SET** button to open the menu.
- The combination instrument starts searching for a suitable cellphone. If the search was successful, the name of the cellphone is displayed in the **Pairing** menu. Press the **SET** button to start the pairing.

**i Info**

The cellphone must be visible via **Bluetooth**® for the cellphone to be found by the combination instrument.

- A message appears on the combination instrument indicating that this is now ready for pairing. The pairing is completed successfully by confirming the **Passkey** on the cellphone and on the combination instrument.

**i Info**


Once the pairing is completed, the registered trademark of the paired cellphone is displayed in the **Phone** menu.

Press the **UP** or **DOWN** button until the paired device is marked. The paired device can be deleted by pressing the **SET** button.

Not every cellphone is suitable for pairing with the combination instrument.

- Move the previously paired device into the range of the combination instrument while the **Bluetooth**® function is active.
  - ✓ The device is automatically paired with the combination instrument.
  - ✗ If the device is not automatically paired with the combination instrument after approx. 30 seconds:
    - Restart combination instrument or **Pairing** repeat procedure.

## 8.19.7 Headset (optional)



### Condition

- The motorcycle is stationary.
  - Function **KTM MY RIDE** (optional) activated.
  - Function **Bluetooth** (optional) activated.
  - The **Bluetooth®** function should also be activated in the device to be paired.
- Press the **SET** button when the menu is closed.
  - Press the **UP** or **DOWN** button until **KTM MY RIDE** is highlighted. Press the **SET** button to open the menu.
  - Press the **UP** or **DOWN** button until **Pairing** is highlighted. Press **SET** button to open the menu.
  - Press **UP** or **DOWN** button until **Headset** is highlighted. Press the **SET** button to open the menu.
  - Press **UP** or **DOWN** button until **Pairing** is highlighted. Press the **SET** button to open the menu.

### Info

This function is only available if the vehicle has **Bluetooth®** hardware.

- The combination instrument starts searching for a suitable communication system. If the search was successful, the name of the communication system is displayed in the **Pairing** menu. Press the **SET** button to select the device. If a PIN code is required for the communication system, this must now be entered. The pairing of a communication system with the combination instrument is now successfully completed.

### Info

The communication system must be in pairing mode for the communication system to be found by the combination instrument. Follow the instructions in the communication system owner's manual.


Once the pairing is completed, the name of the paired communication system is displayed in the **Headset** menu.

Press the **UP** or **DOWN** button until the paired device is marked. The paired device can be deleted by pressing the **SET** button.

Not every communication system is suitable for pairing with the combination instrument.

- Move the previously paired device into the range of the combination instrument while the **Bluetooth®** function is active.
  - ✓ The device is automatically paired with the combination instrument.
  - ✗ If the device is not automatically paired with the combination instrument after approx. 30 seconds:
    - Restart combination instrument or **Pairing** repeat procedure.

## 8.19.8 Audio (optional)

**Condition**

- Function **KTM MY RIDE** (optional) activated.
  - Function **Bluetooth®** (optional) activated.
  - The **Bluetooth®** function should also be activated in the device to be paired.
- Press the **SET** button when the menu is closed.
  - Press the **UP** or **DOWN** button until **KTM MY RIDE** is highlighted. Press the **SET** button to open the menu.

**Warning**

**Danger of accidents** Headphone volume which is too high distracts attention from traffic activity.

- Always select headphone volume which is low enough for you to still clearly hear acoustic signals.

- Press the **UP** or **DOWN** button until **Audio** is highlighted. Press **SET** button to open the menu.

**Info**


This function is only available if the vehicle has **Bluetooth®** hardware.

- Press and hold **UP** button to increase the audio volume.
- Press and hold **DOWN** button to reduce the audio volume.
- Press **UP** button briefly to change to the next audio track.
- Press the **DOWN** button briefly to change to the previous audio track.
- Press **SET** button to play or pause the audio track.

**Info**

The audio function can be added to **Quick Selector 1** or **Quick Selector 2** for easier operation.

## 8.19.9 Telephony (optional)



### Condition

- Function **KTM MY RIDE** activated (optional).
- **Bluetooth®** function is activated.
- The **Bluetooth®** function should also be activated in the device to be paired.
- Communication system linked with appropriate cellphone.



### Warning

**Danger of accidents** Headphone volume which is too high distracts attention from traffic activity.

- Always select headphone volume which is low enough for you to still clearly hear acoustic signals.

- Press the **SET** button to accept an incoming call.



### Info

This function is only available if the vehicle has **Bluetooth®** hardware.


- Press the **BACK** button to reject an incoming call.



### Info

The call duration and contact are displayed. Depending on the cellphone settings, the contact is shown by name.

## 8.19.10 General Info




- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trips/Data** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **General Info** is highlighted. Press the **SET** button to open the menu.

**Date** shows the date.

**ODO** displays the total distance covered.

**Battery** displays the battery voltage.

## 8.19.11 Trip 1



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trips/Data** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Trip 1** is highlighted. Press the **SET** button to open the menu.

**Trip** displays the distance since the last reset, such as between two refueling stops. **Trip** is running and counts up to **9999**.

**ØCons** indicates the average fuel consumption based on **Trip**.


**ØSpeed** indicates the average speed based on **Trip** and **Trip Time**.

**Trip Time** shows the riding time on the basis of **Trip** and runs as soon as a speed signal is received.

**Fuel Range** displays the possible distance you can cover with the fuel reserve.

Press and hold the <b>SET</b> button for at least 3 seconds.	All the entries in the <b>Trip 1</b> menu are reset.
--	--

## 8.19.12 Trip 2



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trips/Data** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Trip 2** is highlighted. Press the **SET** button to open the menu.

**Trip** displays the distance since the last reset, such as between two refueling stops. **Trip** is running and counts up to **9999**.

**ØCons** indicates the average fuel consumption based on **Trip**.


**ØSpeed** indicates the average speed based on **Trip** and **Trip Time**.

**Trip Time** shows the riding time on the basis of **Trip** and runs as soon as a speed signal is received.

**Fuel Range** displays the possible distance you can cover with the fuel reserve.

Press and hold the <b>SET</b> button for at least 3 seconds.	All the entries in the <b>Trip 2</b> menu are reset.
--	--

## 8.19.13 Warning




### Condition

- Message or warning is present.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Trips/Data** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Warning** is highlighted. Press the **SET** button to open the menu.
- Use the **UP** or **DOWN** button to navigate through the warnings.

All the warnings that have occurred are displayed and stored in the **Warning** menu.

## 8.19.14 ABS



- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **ABS** is highlighted. Press the **SET** button to open the submenu.
- Activate the menu item using the **UP** or **DOWN** button.



## Warning

**Danger of accidents** An incorrectly selected ABS mode makes control of the vehicle considerably more difficult.

The ABS modes are each only suitable for certain conditions.

- Always select an ABS mode that is compatible with the surface of the ground.

- Press the **SET** button to select the desired ABS mode.




## Info

The ABS mode can be switched during the journey. Do not open the throttle during the selection.

When the ABS mode **Road** is active, ABS controls both wheels.

When the **Supermoto** ABS mode is active, ABS only controls the front wheel. The rear wheel is not controlled by ABS and may lock during braking maneuvers.

### 8.19.15 MTC+MSR (optional)



#### Condition

- Model with **MTC+MSR**.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **MTC+MSR** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Switch **MTC+MSR** on or off by pressing the **SET** button.



## Info

Do not open the throttle when switching on or off. Press the **SET** button briefly when activating the motorcycle traction control and the engine traction torque control.

Hold down the **SET** button when switching off the motorcycle traction control and engine traction torque control.


When ABS mode **Supermoto** is active, the **MSR** is not active.

After the ignition is switched on, the motorcycle traction control and engine traction torque control are enabled again.

Press and hold the **SET** button for at least 3 seconds.

Switching off the motorcycle traction control and the engine traction torque control.


## 8.19.16 Quick Shift+ (optional)



### Condition

- Model with Quickshifter+.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Motorcycle** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Quick Shift+** is highlighted. Press the **SET** button to open the submenu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch quickshifter + (🗨 p. 50) button on or off.

## 8.19.17 Favourites




### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Favourites** is highlighted. Pressing the **SET** button opens the menu.
- Press the **UP** or **DOWN** button to activate the menu item and select it with the **SET** button.

Up to eight items of information can be selected in the **Favourites** menu.

## 8.19.18 Quick Selector 1




### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Quick Selector 1** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button to activate the menu item and select it with the **SET** button.

Information can be selected in the **Quick Selector 1** menu.

When the menu is closed, the **Quick Selector 1** menu is opened by pressing the **UP** button.

## 8.19.19 Quick Selector 2




### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Quick Selector 2** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button to activate the menu item and select it with the **SET** button.

Information can be selected in the **Quick Selector 2** menu.

When the menu is closed, the **Quick Selector 2** menu is opened by pressing the **DOWN** button.

## 8.19.20 Bluetooth (optional)



### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Bluetooth** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to switch the **Bluetooth**® function on or off.


### Info

This function is only available if the vehicle has **Bluetooth**® hardware.

The **Bluetooth**® function can only be used in conjunction with **KTM MY RIDE** (optional).

When the **Bluetooth**® function is switched on and the device is connected, the **Bluetooth**® symbol appears in the display of the combination instrument.

## 8.19.21 Display Theme




### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Display Theme** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to set up automatic day-night mode or permanent night mode.

### Info

In both display modes, the background lighting is brightened or dimmed depending on the amount of light that the ambient light sensor detects.

## 8.19.22 Shift Light



### Condition


- The motorcycle is stationary.
- **ODO** > 1,000 km (621 mi).
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Shift Light** is highlighted. Press **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Switch the shift warning light on or off or set the engine speed for the gear shift recommendation by pressing the **SET** button.



### Info

When the engine speed reaches **RPM 1**, the engine speed display flashes red.  
When the engine speed reaches **RPM 2**, the engine speed display flashes and the color changes.


## 8.19.23 Setting the time and date



### Condition


The motorcycle is stationary.

- Press the **SET** button when the menu is closed.
- Press **UP** or **DOWN** button until **Settings** appears. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Time/Date** is highlighted. Press the **SET** button to open the menu.



### Setting the clock


- Press **UP** or **DOWN** button until the time is marked.
- Press the **SET** button.
  - ✓ The hour flashes and is underlined.
- Press **UP** or **DOWN** button until the current hour is set.
- Press the **SET** button.
  - ✓ The minutes flash and are underlined.
- Press **UP** or **DOWN** button until the current minute is set.
- Press the **SET** button.
  - ✓ The time is stored.



## Setting the date

- Press **UP** or **DOWN** button until the date is marked.
- Press the **SET** button.
  - ✓ The day flashes and is underlined.
- Press **UP** or **DOWN** button until the current day is set.
- Press the **SET** button.
  - ✓ The month flashes and is underlined.
- Press **UP** or **DOWN** button until the current month is set.
- Press the **SET** button.
  - ✓ The year flashes and is underlined.
- Press **UP** or **DOWN** button until the current year is set.
- Press the **SET** button.
  - ✓ The date is stored.


### 8.19.24 Distance



#### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Distance** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired unit.


### 8.19.25 Fuel Cons



#### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Units** is highlighted. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Fuel Cons** is highlighted. Press the **SET** button to open the menu.
- Activate the menu item using the **UP** or **DOWN** button.
- Press the **SET** button to confirm the desired unit.

### 8.19.26 Language




#### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Language** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button to activate the menu item and select it with the **SET** button.

The menu languages are US English, UK English, German, Italian, French, and Spanish.

### 8.19.27 Service




#### Condition

- The motorcycle is stationary.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Service** is highlighted. Press **SET** button to open the menu.

The next service due is shown in the **Service** menu.

### 8.19.28 Extra Functions



#### Condition

- The motorcycle is stationary.
- Motorcycle with optional supplementary function.
- Press the **SET** button when the menu is closed.
- Press the **UP** or **DOWN** button until **Settings** is highlighted. Press **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Extra Functions** is highlighted. Press **SET** button to open the menu.
- Use the **UP** or **DOWN** button to navigate through the extra functions.

The optional extra functions are listed in **Extra Functions**.

#### **i** Info

The current **KTM PowerParts** and the available software for your vehicle can be found on the KTM website.

## 9.1 Advice on preparing for first use



### Danger

**Danger of accidents** A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



### Warning

**Risk of injury** Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.



### Warning

**Danger of crashing** Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

- Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.



### Warning

**Danger of accidents** Non-approved or non-recommended tires and wheels impact the handling characteristic.

- Only use tires/wheels approved by KTM with the corresponding speed index.



### Warning

**Danger of accidents** New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.  
Run-in distance 200 km (124 mi)



### Info

When using the vehicle, remember that others may feel disturbed by excessive noise.

- Ensure that the pre-sales inspection work has been carried out by an authorized KTM workshop.
  - ✓ The delivery certificate is transferred upon vehicle handover.
- Read the entire Owner's Manual before riding for the first time.
- Get to know the controls.
- Get used to the handling characteristic of the motorcycle on suitable terrain before undertaking a more challenging ride. Also, ride as slowly as possible to get a better feeling for the motorcycle.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
- Run the engine in. (📖 p. 47)

## 9.2 Running in the engine

- During the running-in time, do not exceed the specified engine speed.

Guideline

Maximum engine speed	
During first: 1,000 km (620 mi)	7,500 rpm



### Info

During the running-in phase, the shift warning light is set to a specified value and cannot be changed.

- Avoid fully opening the throttle.



## 9.3 Loading the vehicle



### Warning

**Danger of accidents** Total weight and axle loads influence the handling characteristic.

The total weight consists of: operational motorcycle with a full tank, rider and, if necessary, a passenger with protective clothing and helmet, and, if necessary, mounted luggage.

- Do not exceed the maximum permissible overall weight or the axle loads.



### Warning

**Danger of accidents** Improper mounting of cases, tank rucksacks or other luggage impairs the handling characteristics.

Luggage mounted incorrectly can slip while the vehicle is in motion.

- Mount and secure all luggage according to the manufacturer's instructions.
- Check that your luggage is fixed properly at regular intervals.



### Warning

**Danger of accidents** The luggage system will be damaged if it is overloaded.

- Read the manufacturer information on maximum payload when mounting cases.



### Warning

**Danger of accidents** Luggage which has slipped impairs visibility.

If the tail light is covered, you are less visible to traffic behind you, especially when it is dark.

- Check that your luggage is fixed properly at regular intervals.



### Warning

**Danger of accidents** A high payload alters the handling characteristic and increases the stopping distance.

- Adapt your speed to your payload.

- If luggage is carried, ensure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.
- Do not exceed the maximum permissible weight and maximum permissible axle loads.

Guideline


Maximum permissible overall weight	355 kg (783 lb.)
Maximum permissible front axle load	135 kg (298 lb.)
Maximum permissible rear axle load	230 kg (507 lb.)



## 10.1 Checks and maintenance measures when preparing for use

### **i** Info

Before every trip, check the condition of the vehicle and ensure that it is roadworthy. The vehicle must be in perfect technical condition when it is being operated.



- Check the engine oil level. (📖 p. 102)
- Check the front brake fluid level. (📖 p. 73)
- Check the rear brake fluid level. (📖 p. 76)
- Check that the brake linings of the front brake are secured. (📖 p. 75)
- Check that the brake linings of the rear brake are secured. (📖 p. 78)
- Check that the brake system is functioning properly.
- Check the coolant level in the compensating tank. (📖 p. 94)
- Check for chain dirt accumulation. (📖 p. 64)
- Check the chain tension. (📖 p. 65)
- Check the tire condition. (📖 p. 84)
- Check tire pressure. (📖 p. 85)
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check that the electrical system is functioning properly.
- Check that luggage is properly secured.
- Sit on the motorcycle and check the rear mirror setting.
- Check the fuel level.

## 10.2 Starting



### **Danger**

**Danger of poisoning** Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



### **Caution**

**Danger of accidents** Electronic components and safety devices will be damaged if the 12-V battery is discharged or missing.

If the 12-V battery is discharged or defective, malfunctions in the vehicle electronics can occur, especially when starting.

- Never operate the vehicle with a discharged 12-V battery or without a 12-V battery.

### **Note**

**Engine damage** Unfiltered intake air has a negative effect on the service life of the engine.


Dust and dirt will enter the engine without an air filter.

- Only operate the vehicle if it is equipped with an air filter.

### **Note**

**Engine damage** High revving speed with a cold engine negatively impacts the lifespan of the engine.

- Always run the engine warm at a low speed.



- Unlock the steering. (🔒 p. 20)
- Sit on the vehicle, take the weight off of the side stand, and move it all the way up with your foot.
- Turn the emergency OFF switch to the position ○.
- Switch on the ignition by turning the ignition key to the position ○.

**Guideline**

To avoid malfunctions in the control unit communication, do not switch the ignition off and on in rapid succession.

- ✓ After you switch on the ignition, you can hear the fuel pump working for about two seconds. The function check of the combination instrument is run at the same time.
- Shift the transmission into neutral.
- ✓ Green idle indicator lamp **N** lights up.
- ✓ The ABS warning lamp lights up and goes out again after starting off.
- Briefly press the start button (🔌).



**Info**

Do not press the start button until the combination instrument function check has finished.

Do not open the throttle to start.

If the starting attempt is unsuccessful, wait for 15 seconds before making another attempt at starting.

After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other malfunctions instead.

This motorcycle is equipped with a safety starting system. You can only start the engine if the transmission is in neutral or if the clutch lever is pulled when a gear is engaged. If the side stand is folded out and you shift into gear and release the clutch lever, the engine stops.



## 10.3 Starting off

- Pull the clutch lever, shift into first-gear, release the clutch lever slowly and at the same time open the throttle carefully.




**Tip**

If the engine stalls while starting off, only pull the clutch lever and press the start button. The transmission must not be shifted into neutral.



## 10.4 quickshifter + (optional)



If the quickshifter + is activated, you can shift up and down without actuating the clutch.

Because there is no need to close the throttle grip, uninterrupted gear shifts are possible.

The quickshifter + uses the shifter shaft position to check whether or not a shift should be initiated, and sends a corresponding signal to the engine control.

If the quickshifter + is disabled in the combination instrument, the clutch needs to be actuated in the normal way for each shift.

## 10.5 Shifting, riding



### Warning

**Danger of accidents** Abrupt load alterations can cause the vehicle to get out of control.

- Avoid abrupt load alterations and sudden braking actions.
- Adapt your speed to the road conditions.



### Warning

**Danger of accidents** If you change down at high engine speed, the rear wheel blocks and the engine races.

- Do not change into a low gear at high engine speed.



### Warning

**Danger of accidents** An incorrect ignition key position causes malfunctions.

- Do not change the ignition key position while driving.



### Warning

**Danger of accidents** Adjustments to the vehicle distract attention from traffic activity.

- Make all adjustments when the vehicle is at a standstill.



### Warning

**Risk of injury** The passenger may fall from the motorcycle if they conduct themselves incorrectly.

- Ensure that the passenger sits correctly on the passenger seat, places his or her feet on the passenger foot pegs and holds on to the rider or the grab handles.
- Note the regulations governing the minimum age of passengers in your country.



### Warning

**Danger of accidents** A risky riding style constitutes a major risk.

- Comply with traffic regulations and ride defensively and with foresight to detect sources of danger as early as possible.



## Warning

**Danger of accidents** Cold tires have reduced road grip.

- Ride the first miles carefully on every journey at moderate speed until the tires reach operating temperature.



## Warning

**Danger of accidents** New tires have reduced road grip.

The contact surface on new tires is not yet roughened.

- Run in new tires with moderate riding and only gradually increase the lean angle.  
Run-in distance 200 km (124 mi)



## Warning

**Danger of accidents** Improper mounting of cases, tank rucksacks or other luggage impairs the handling characteristics.

Luggage mounted incorrectly can slip while the vehicle is in motion.

- Mount and secure all luggage according to the manufacturer's instructions.
- Check that your luggage is fixed properly at regular intervals.



## Warning

**Danger of accidents** A fall can damage the vehicle more seriously than it may first appear.

- Check the vehicle after a fall as you do when preparing for use.

## Note


**Engine failure** Overheating damages the engine.

- If the coolant temperature warning is displayed, stop immediately and take care not to endanger yourself or other traffic participants in the process.
- Allow the engine and cooling system to cool down.
- Check and, if necessary, correct the coolant level on the cooling system while it is in a cooled state.



## Info

If unusual noises occur while riding, stop immediately (taking care not to endanger yourself or other road users in the process), switch off the engine and contact an authorized KTM workshop.






- Shift into a higher gear when conditions allow (incline, road situation, etc.).
- Release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever, and open the throttle.



## Info


The gear positions can be seen in the figure. The idle position is between the first and second gears. First gear is used for starting off or for steep inclines.

- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is  $\frac{3}{4}$  open. This will barely reduce the speed, but fuel consumption will be considerably lower.
- Accelerate only up to a speed suitable for the road surface and weather conditions. Particularly in bends, do not shift, and accelerate very carefully.

- Brake if necessary and close the throttle at the same time in order to shift down.
- Pull clutch lever and shift into a lower gear, release the clutch lever slowly, and open the throttle or shift again.
- Switch off the engine if you are likely to be running at idle speed or stationary for a long time.
- If the engine stalls (e.g. at an intersection), just pull the clutch lever and press the start button. The transmission must not be shifted into neutral.
- If the oil pressure warning lamp  lights up during a trip, stop as soon as it is safe to do so and switch off the engine. Contact an authorized KTM workshop.
- If the malfunction indicator lamp  lights up during a trip, please contact an authorized KTM workshop as soon as possible.
- If the general warning lamp  lights up during a trip, an operating safety (warning) message was detected.

### Info


All warnings which have occurred are displayed and stored in the **Warning** menu until these are no longer active.



- If the Quickshifter+ (optional) is activated in the combination instrument, you can shift up in the engine speed range shown without pulling the clutch lever.

### Info

The minimum engine speed before shifting up in revolutions per minute is shown in the figure. Pull the shift lever to the stop quickly without changing the throttle twist grip position.



- If the quickshifter + (optional) is activated the combination instrument, you can shift down in the engine speed range shown without pulling the clutch lever.

### Info

The maximum engine speed before shifting down in revolutions per minute is shown in the figure. Press the shift lever to the stop quickly without changing the throttle twist grip position.

## 10.6 Applying the brakes



### Warning

**Danger of accidents** Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.



### Warning

**Danger of accidents** A spongy pressure point on the front or rear brake reduces braking efficiency.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



## Warning

**Danger of accidents** The brake system fails in the event of overheating.

If the foot brake lever is not released, the brake linings drag continuously.

- Take your foot off the foot brake lever if you do not want to brake.



## Warning

**Danger of accidents** Higher total weight increases the stopping distance.

- Take the longer stopping distance into account when carrying a passenger or luggage with you.



## Warning

**Danger of accidents** Salt on the roads impairs the brake system.

- Brake carefully several times to remove salt from the brake linings and the brake discs.



## Warning

**Danger of accidents** ABS may increase the stopping distance in certain situations.

- Adjust application of the brakes to the respective riding situation and riding surface conditions.

- When braking, release the throttle and apply the front and rear brakes at the same time.



## Info

When the ABS is enabled, you can achieve maximum braking power even on low grip surfaces such as sandy, wet, or slippery terrain without locking of the wheels.



## Warning

**Danger of accidents** The rear wheel can lock due to the engine braking effect.

- Pull in the clutch, if you perform emergency or full braking, or if you brake on a slippery ground.



## Warning

**Danger of accidents** Banked or laterally sloping ground reduces the maximum possible delay.

- If possible finish braking before going into a bend.

- Always finish the braking before you go into a bend. Shift down to a lower gear appropriate to your speed.
- Use the braking effect of the engine on long downhill stretches. Shift back one or two gears, but do not over-rev the engine when doing so. This means that significantly less braking is required and the brake system does not overheat.



## 10.7 Stopping, parking



## Warning

**Risk of injury** People who act without authorization endanger themselves and others.

- Do not leave the vehicle unattended if the engine is running.
- Protect the vehicle against access by unauthorized persons.
- Lock the steering and remove the ignition key if you leave the vehicle unattended.



## Warning

**Danger of burns** Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

## Note

**Material damage** The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

## Note

**Fire hazard** Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.

- 
- Apply the brakes on the motorcycle.
  - Shift the transmission into neutral.
  - Switch off the ignition by turning the ignition key to the position ☒.

## Info

If the engine is switched off with the emergency OFF switch and the ignition remains switched on in the ignition lock, the power supply to most electrical power consumers remains uninterrupted and this discharges the 12-V battery. You should therefore always switch off the engine with the ignition lock – the emergency OFF switch is intended for emergencies only.

- 
- Park the motorcycle on a firm surface.
  - Swing side stand forward with your foot as far as it will go and lean the vehicle on it.
  - Lock the steering. (📖 p. 19)

## 10.8 Transport

### Note

**Material damage** The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.


The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

### Note

**Fire hazard** Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.



- Switch off the engine and remove the ignition key.
- Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.


## 10.9 Towing in the event of a breakdown

### Note

**Danger of damage** Towing away using a towing vehicle is not an appropriate vehicle recovery method.

Damage to the drive train or transmission may occur during towing.

- Do not use towing equipment where the wheels of the broken down vehicle remain on the road and rotate as it is towed.
- Always transport a broken down vehicle on a trailer or on the loading area of a transport vehicle.



- Ensure that the broken down vehicle is properly secured on the trailer or transport vehicle.
- Observe local regulations for the recovery of broken down vehicles.

## 10.10 Refueling



### Danger

**Fire hazard** Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



### Warning

**Danger of poisoning** Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.

### Note

**Material damage** Inadequate fuel quality causes the fuel filter to quickly become clogged.

In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system.

- Refuel only with clean fuel that meets the specified standards. (Your authorized KTM workshop will be glad to help.)



### Note

**Environmental hazard** Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.

# 10 RIDING INSTRUCTIONS



- Switch off the engine.
- Open the fuel tank filler cap. (📖 p. 20)
- Fill the fuel tank with fuel up to the lower edge **1** of the fuel filler.

Total fuel tank capacity, approx.	14 l (3.7 US gal)	Super unleaded (ROZ 95) (📖 p. 122)
-----------------------------------	----------------------	--

- Close the fuel tank filler cap. (📖 p. 21)



V02513-10

## 11.1 Additional information

Any further work that results from the service work must be ordered separately and invoiced separately. Different service intervals may apply in your country, depending on the local operating conditions. Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule is available for authorized KTM dealers for the electronic proof of service. Your authorized KTM dealer will be happy to advise you.

## 11.2 Service work

	every 48 months	every 24 months	every 12 months	every 15,000 km (9,300 mi)	every 7,500 km (4,650 mi)	after 1,000 km (620 mi)
Read out the fault memory using the KTM diagnostics tool. 🛠️	○	●	●	●	●	●
Program the shift shaft sensor. 🛠️	○	●	●			
Check that the electrical system is functioning properly.	○	●	●	●	●	●
Check that the brake linings of the front brake are secured. (📖 p. 75)	○	●	●	●	●	●
Check that the brake linings of the rear brake are secured. (📖 p. 78)	○	●	●	●	●	●
Check the brake discs. (📖 p. 73)	○	●	●	●	●	●
Check the brake lines for damage and leakage.	○	●	●	●	●	●
Check the front brake fluid level. (📖 p. 73)	○	●	●	●		
Change the front brake fluid. 🛠️					●	●
Check the rear brake fluid level. (📖 p. 76)	○	●	●	●		
Change the rear brake fluid. 🛠️					●	●
Change the engine oil and the oil filter, clean the oil screens. 🛠️ (📖 p. 102)	○	●	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage hoses, etc.) and sleeves for cracking, tightness, and correct routing. 🛠️	○	●	●	●	●	●
Empty the drainage hoses. 🛠️	○	●	●	●	●	●
Check the cables for damage and routing without sharp bends. 🛠️	○	●	●	●	●	●
Check the frame. 🛠️			●			
Check the link fork. 🛠️			●			
Check the fork bearing for play. 🛠️		●	●			
Check the steering head bearing for play. 🛠️	○	●	●			
Check the wheel bearing for play. 🛠️		●	●			
Check the shock absorber and fork for leaks.	○	●	●	●	●	●
Check the tire condition. (📖 p. 84)	○	●	●	●	●	●
Check tire pressure. (📖 p. 85)	○	●	●	●	●	●
Check the chain, rear sprocket, and engine sprocket. (📖 p. 66)		●	●	●	●	●
Check the chain tension. (📖 p. 65)	○	●	●	●	●	●
Grease all moving parts (e.g. side stand, hand lever, chain, etc.) and check for smooth operation. 🛠️	○	●	●	●	●	●
Check that the throttle cables are undamaged, routed without sharp bends, and set correctly. 🛠️	○	●	●	●	●	●
Check the valve clearance, change the spark plug. 🛠️			●			
Change the air filter, clean the air filter box. 🛠️		●	●			

# 11 SERVICE SCHEDULE


	every 48 months					
	every 24 months					
	every 12 months					
	every 15,000 km (9,300 mi)					
	every 7,500 km (4,650 mi)					
	after 1,000 km (620 mi)					
Check the headlight setting. (📖 p. 92)	○	●	●			
Check the tightness of the safety-relevant screws and nuts which are easily accessible. 🛠️	○	●	●	●	●	●
Clean the dust boots of the fork legs. (📖 p. 62)		●	●			
Check that the radiator fan is functioning properly. 🛠️	○	●	●	●	●	●
Check the coolant level in the compensating tank. (📖 p. 94)	○	●	●	●	●	
Checking the antifreeze. 🛠️		●	●		●	
Change the coolant. (📖 p. 98)						●
Final check: Final check: Check the vehicle for safe operation and take a test ride. 🛠️	○	●	●	●	●	●
Read out the error memory after the test ride using the KTM diagnostics tool. 🛠️	○	●	●	●	●	●
Set the service interval display. 🛠️	○	●	●	●	●	●
Enter electronic proof of service. 🛠️	○	●	●	●	●	●

- One-time interval
- Periodic interval

## 12.1 Adjusting the compression damping of the fork

**i** **Info**

The hydraulic compression damping determines the fork suspension behavior.



- Turn adjuster ① clockwise all the way to the stop.

**i** **Info**

Adjuster ① is located at the upper end of the left fork leg.

The compression damping is located in left fork leg **COMP** (white adjuster). The rebound damping is located in right fork leg **REB** (red adjuster).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Compression damping	
Standard	15 clicks

**i** **Info**


Turn clockwise to increase damping; turn counterclockwise to reduce damping during compression.



## 12.2 Adjusting the rebound damping of the fork

**i** **Info**

The hydraulic rebound damping determines the fork suspension behavior.



- Turn adjuster ① clockwise all the way to the stop.

**i** **Info**

Adjuster ① is located at the upper end of the right fork leg.

The rebound damping is located in right fork leg **REB** (red adjuster). The compression damping is located in left fork leg **COMP** (white adjuster).

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Standard	15 clicks

**i** **Info**

Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.



## 12.3 Adjusting the spring preload of the shock absorber ↩



### Warning

**Danger of accidents** Modifications to the suspension setting may seriously alter the handling characteristic.

- Ride slowly to start with after making adjustments to get the feel of the new handling characteristic.



### Info

The spring preload defines the initial status of the spring operation on the shock absorber. The best spring preload setting is achieved when it is set for the weight of the rider and that of any luggage and a passenger, thus ensuring an ideal compromise between handling and stability.



- Adjust the spring preload by turning adjusting ring **1** using the hook wrench from the tool set.

Guideline

Spring preload	
Standard	3 clicks

Hook wrench, shock absorber (90529077000)	
---	--



### Info

The spring preload can be set to 10 different positions.


## 12.4 Adjusting the rebound damping of the shock absorber



### Caution

**Risk of injury** Parts of the shock absorber will move around if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided. (Your authorized KTM workshop will be glad to help.)



- Turn adjusting screw **1** clockwise up to the last perceptible click.
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Rebound damping	
Standard	3 clicks



### Info


Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.

## 13.1 Raising the motorcycle with rear lifting gear

### Note

**Danger of damage** The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



- Mount the supports of the lifting gear.
- Insert the adapter in the rear lifting gear.

Retaining adapter (61029955244)
---------------------------------

Rear wheel work stand (69329955000)
-------------------------------------

- Stand the motorcycle upright, align the lifting gear to the link fork and the adapters, and raise the motorcycle.




## 13.2 Removing the rear of the motorcycle from the lifting gear

### Note

**Danger of damage** The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



- Secure the motorcycle against falling over.
- Remove the rear lifting gear and lean the vehicle on side stand ①.
- Remove bushings kit.




## 13.3 Lifting the motorcycle with the front lifting gear

### Note

**Danger of damage** The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.




### Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)

### Condition

- Remove protection cap ①.

# 13 SERVICE WORK ON THE CHASSIS



- Move the handlebar to the straight-ahead position. Position the lifting gear.

Mounting pin (69329965030)

Front wheel work stand, large (69329965100)



### Info

Always raise the motorcycle at the rear first.


- Lift the motorcycle at the front.

## 13.4 Taking the motorcycle off the front lifting gear

### Note


**Danger of damage** The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.



### Main work

- Secure the motorcycle against falling over.
- Remove the front lifting gear.



- Mount protection cap ①.


### Finishing work

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)

## 13.5 Cleaning the dust boots of the fork legs

### Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)



### Main work

- Push dust boots **1** of both fork legs downward.



### Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



### Warning

**Danger of accidents** Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.

- Clean and oil the dust boots and inside fork tubes of both fork legs.

Universal oil spray (📖 p. 123)

- Press the dust boots back into the installation position.
- Remove the excess oil.

### Finishing work


- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)

## 13.6 Removing the front rider's seat




- Insert the ignition key in seat lock **1** and turn it clockwise.
- Raise the rear of the front rider's seat, pull it toward the rear, and remove it upward.
- Remove the ignition key from the seat lock.

## 13.7 Mounting the front rider's seat



- Attach recesses **1** on the front rider's seat to the fuel tank, push the front rider's seat forward, and lower at the rear.
- ✓ The pin **2** locks audibly in place.
- Check that the front rider's seat is mounted correctly.

## 13.8 Checking for chain dirt accumulation



- Check the chain for coarse dirt accumulation.
  - » If the chain is very dirty:
    - Clean the chain. (📖 p. 64)

## 13.9 Cleaning the chain



### Warning

**Danger of accidents** Lubricants on the tires reduces the road grip.

- Remove lubricants from the tires using a suitable cleaning agent.



### Warning

**Danger of accidents** Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



### Note


**Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



### Info

The service life of the chain depends largely on its maintenance.



### Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)

### Main work

- Clean the chain regularly.
- Rinse off the loose dirt with a gentle jet of water.
- Remove grease residue with chain cleaner.

Chain cleaner (📖 p. 123)

- After drying, apply chain spray.

Street chain spray (📖 p. 123)

### Finishing work

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)

## 13.10 Checking the chain tension




### Warning

**Danger of accidents** Incorrect chain tension damages components and results in accidents.

If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.



### Preparatory work

- Raise the motorcycle with the rear lifting gear. (🔧 p. 61)

### Main work

- Shift the transmission into neutral.
- In the area after the chain sliding guard, press the chain upward toward the link fork and measure chain tension **A**.

### Info

Top chain section **B** must be taut.

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	5 ... 7 mm (0.2 ... 0.28 in)
---------------	------------------------------

- » If the chain tension does not meet the specification:
  - Adjust the chain tension. (🔧 p. 65)
- Remove the rear of the motorcycle from the lifting gear. (🔧 p. 61)

## 13.11 Adjusting the chain tension



### Warning

**Danger of accidents** Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

### Preparatory work

- Raise the motorcycle with the rear lifting gear. (🔧 p. 61)
- Check the chain tension. (🔧 p. 65)



### Main work

- Loosen nut ①.
- Loosen nuts ②.
- Adjust the chain tension by turning adjusting screws ③ left and right.

#### Guideline

Chain tension	5 ... 7 mm (0.2 ... 0.28 in)
Turn the adjusting screws ③ on the left and right so that the markings on the left and right chain adjusters ④ are in the same position relative to the reference marks ①. The rear wheel is then correctly aligned.	

### **i** Info

The top chain section must be taut. Chain wear is not always even, so you should check the setting at different chain positions.

- Tighten nuts ②.
- Make sure that chain adjusters ④ are fitted correctly on adjusting screws ③.
- Tighten nut ①.

#### Guideline

Nut, rear wheel spindle	M14x1.5	100 Nm (73.8 lbf ft)
-------------------------	---------	-------------------------

### Finishing work

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)

## 13.12 Checking the chain, rear sprocket, and engine sprocket

### Preparatory work


- Raise the motorcycle with the rear lifting gear. (📖 p. 61)


### Main work

- Shift the transmission into neutral.
- Check the rear sprocket and engine sprocket for wear.
  - » If the rear sprocket and engine sprocket are worn:
    - Change the drivetrain kit. 🛠️

### **i** Info

The engine sprocket, rear sprocket, and chain should always be replaced together.





- Pull on the lower chain section with the specified weight **A**.

Guideline

Weight, chain wear measurement	15 kg (33 lb.)
--------------------------------	----------------


- Measure distance **B** of 20 chain rollers in the lower chain section.

**i Info**  
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance <b>B</b> from 20 chain rollers at the longest chain section	304 mm (11.97 in)
--	-------------------

- » If distance **B** is greater than the specified measurement:
  - Change the drivetrain kit. 🛠️

**i Info**  
When a new chain is mounted, the rear sprocket and engine sprocket should also be changed. New chains wear out faster on old, worn sprockets.



- Push the chain up in the area behind the chain guide.
- Check the chain sliding guard for wear.
  - » If the chain sliding guard has lost material due to wear to the extent that, in area **C**, the drilled hole of screw **1** is visible from above:
    - Change the chain sliding guard. 🛠️
- Check that the chain sliding guard is firmly seated.
  - » If the chain sliding guard is loose:
    - Tighten screws on the chain sliding guard.

### Finishing work

- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)


## 13.13 Removing the fuel tank cover 🛠️

### Preparatory work


- Remove the front rider's seat. (📖 p. 63)

### Main work

- Remove screws **1**.




# 13 SERVICE WORK ON THE CHASSIS




- Pull the fuel tank cover from holding lugs ②.
- Pull holding lugs ③ out of the brackets.
- Pull the fuel tank cover off towards the rear and take off upwards.

## 13.14 Mounting the fuel tank cover



### Main work

- Position the fuel tank cover and slide it forward.
- ✓ Holding lugs ① engage in the brackets.
- Position brackets with rubber bushings ② on holding lugs and slide down.



- Mount and tighten screws ③.

### Guideline

Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------


- Check that the fuel tank cover is mounted correctly.

## Finishing work


- Mount the front rider's seat. (📖 p. 63)



### 13.15 Removing the left side cover 🗑️




- Remove screws ①.
- Remove screws ② with the bushings.



- Remove screws ③ with the bushings.
- Pull off holding lugs in area A and in area B.
- Take off the side cover.




### 13.16 Installing the left side cover 🗑️



- Position the side cover.
- Push on the side cover in area A and area B.
- ✓ Make sure the holding lugs engage in the brackets.
- Mount screws ① with the bushings and tighten.

#### Guideline

Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------



- Mount and tighten screws ②.

#### Guideline

Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------


- Mount screws ③ with the bushings and tighten.

#### Guideline


Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------



## 13.17 Removing the right side cover ↩




- Remove screws ①.
- Remove screws ② with the bushings.



- Remove screws ③ with the bushings.
- Pull off holding lugs in area A and in area B.
- Take off the side cover.


## 13.18 Installing the right side cover ↩



- Position the side cover.
- Push on the side cover in area A and area B.  
✓ Make sure the holding lugs engage in the brackets.
- Mount screws ① with the bushings and tighten.

Guideline

Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------



- Mount and tighten screws ②.

Guideline


Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------

- Mount screws ③ with the bushings and tighten.


Guideline

Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
------------------------	----	-------------------


## 13.19 Removing the front fender



- Remove screws ①.
- Remove screws ② and reflectors.
- Take the fender off to the front.




## 13.20 Installing the front fender




- Position the front fender.
- Mount and tighten screws ①.
- Mount and tighten screws ② and reflectors.

Guideline

Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
---------------------------	----	-------------------



## 14.1 Anti-lock braking system (ABS)



The **ABS** module **1**, which consists of a hydraulic unit, ABS control unit, and return pump, is installed under the fuel tank. One wheel speed sensor **2** is located in each case on the front and the rear wheel.



### Warning

**Danger of accidents** Changes to the vehicle impair the function of the ABS.

- Do not make any changes to the suspension travel.
- Only use spare parts on the brake system which have been approved and recommended by KTM.
- Only use tires/wheels approved by KTM with the corresponding speed index.
- Maintain the specified tire pressure.
- Ensure that service work and repairs are performed professionally. (Your authorized KTM workshop will be glad to help.)

The **ABS** is a safety system that prevents the wheels locking when driving straight ahead or when cornering (within the limits of physics).



### Warning

**Danger of accidents** Driving aids can reduce the probability of a fall only within physical limits.

It is not always possible to compensate for certain riding situations, for example with luggage loaded with a high center of gravity, varying road surfaces, steep descents or full braking without disengaging the gear.

- Adapt your riding style to the road conditions and your driving ability.

ABS has two operating modes: the **Road** and **SupermotoABS** modes.

In **Road** ABS mode, the ABS controls both wheels.

In ABS mode **Supermoto**, the ABS only controls the front wheel.

A corresponding text appears in the combination instrument to remind you of the active ABS mode **Supermoto**.



### Info

In the **Supermoto** ABS mode, the rear wheel may lock and there is a risk of falling.

The curve dependent control is only active in ABS mode **Road**.

The ABS operates with two independent brake circuits (front and rear brakes). During normal operation, the brake system operates like a conventional brake system without ABS. When the ABS control unit detects a locking tendency in a wheel, ABS begins regulating the brake pressure. The control function causes a slight pulsing of the hand and foot brake levers.

The ABS warning lamp **3** must light up after the ignition is switched on and go out after starting off. If it does not go out


after starting off or if it lights up while riding, this indicates a malfunction in the antilock brake system. In this case, the ABS is no longer enabled and the wheels may lock during braking. The brake system itself stays functional; only ABS control is not available.

The ABS warning lamp may also light up if the rotating speeds of the front and rear wheels differ greatly under extreme riding conditions, for example when making "wheelies" or if the rear wheel spins. This causes the ABS to switch off.

To reactivate the ABS, stop the vehicle and switch off the ignition. The ABS is reactivated when the vehicle is switched on again. The ABS warning lamp goes out after starting off.

**14.2 Checking the brake discs**

**Warning**  
**Danger of accidents** Worn-out brake discs reduce the braking effect.  
 – Make sure that worn-out brake discs are replaced immediately. (Your authorized KTM workshop will be glad to help.)



- Check the front and rear brake disc thickness at multiple points for the dimension **A**.

**i Info**  
 Wear will reduce the thickness of the brake disc at contact surface **1** of the brake linings.

Brake discs - wear limit	
front	4.5 mm (0.177 in)
rear	3.6 mm (0.142 in)

- » If the brake disc thickness is less than the specified value.
  - Change the front brake disc. 🛠️
  - Change the rear brake disc. 🛠️
- Check the front and rear brake discs for damage, cracking, and deformation.
  - » If the brake disc exhibits damage, cracking, or deformation:
    - Change the front brake disc. 🛠️
    - Change the rear brake disc. 🛠️

**14.3 Checking the front brake fluid level**

**Warning**  
**Danger of accidents** An insufficient brake fluid level will cause the brake system to fail.  
 If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.  
 – Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



## Warning

**Danger of accidents** Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized KTM workshop will be glad to help.)



- Move the brake reservoir mounted on the handlebar into a horizontal position.
- Check the brake fluid level in the level viewer **1**.
  - » If the brake fluid level is below the **MIN** marking:
    - Add front brake fluid. 📖 (p. 74)

## 14.4 Adding front brake fluid 📖



## Warning

**Danger of accidents** An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



## Warning

**Skin irritation** Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



## Warning

**Danger of accidents** Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized KTM workshop will be glad to help.)




## Note

**Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

**i Info**

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.



**Preparatory work**

- Check that the brake linings of the front brake are secured. (📖 p. 75)

**Main work**

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Take off cover ② with membrane ③.
- Add brake fluid up to the marking A.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 121)
--

- Position the cover with the membrane. Mount and tighten the screws.

**i Info**

Use water to immediately clean up any brake fluid that has overflowed or spilled.



## 14.5 Checking that the brake linings of the front brake are secured



**Warning**

**Danger of accidents** Worn-out brake linings reduce the braking effect.

- Ensure that worn-out brake linings are replaced immediately. (Your authorized KTM workshop will be glad to help.)




**Warning**

**Danger of accidents** Damaged brake discs reduce the braking effect.

If the brake linings are not changed in time, the brake lining carriers grind against the brake disc. As a consequence, the braking effect is greatly reduced and the brake discs are destroyed.

- Check the brake linings regularly.



- Check the brake linings for lining thickness A.

Minimum thickness A	$\geq 1 \text{ mm } (\geq 0.04 \text{ in})$
---------------------	---

- » If it is less than the minimum thickness:
  - Change the brake linings of the front brake. 🛠️
- Check the brake linings for damage and cracking.
  - » If there is damage or cracking:
    - Change the brake linings of the front brake. 🛠️
- Check that the brake linings are secured.
  - » If the brake linings are not secured correctly:
    - Secure brake linings, replace with new parts if necessary.



## 14.6 Checking the rear brake fluid level



### Warning

**Danger of accidents** An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.


- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



### Warning

**Danger of accidents** Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized KTM workshop will be glad to help.)



- Position the vehicle upright.
- Check the brake fluid level in the brake fluid reservoir.
  - » If the fluid level reaches the **MIN** marking ①:
    - Add rear brake fluid. 🛠️ (📖 p. 76)

## 14.7 Adding rear brake fluid 🛠️



### Warning

**Danger of accidents** An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.

- Check the brake system and do not continue riding until the problem is eliminated. (Your authorized KTM workshop will be glad to help.)



### Warning

**Skin irritation** Brake fluid is a harmful substance.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



## Warning

**Danger of accidents** Brake fluid which is too old or of the wrong type impairs the function of the brake system.

- Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized KTM workshop will be glad to help.)
- Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized KTM workshop will be glad to help.)



## Note

**Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



## Info

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

### Preparatory work


- Check that the brake linings of the rear brake are secured. (📖 p. 78)

### Main work


#### Condition

The screw cap is locked.

- Remove screw ❶ and take off the screw cap lock.



H01142-10



V02519-10

- Stand the vehicle upright.
- Remove screw cap ❷ with membrane ❸.
- Add brake fluid up to the marking A.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 121)

- Mount the screw cover with the membrane.



## Info

Use water to immediately clean up any brake fluid that has overflowed or spilled.


### Condition

The screw cap is locked.

- Position the screw cap lock and mount and tighten screw ❶.

#### Guideline

Screw, compensating tank cap lock, rear brake	M5	7 Nm (5.2 lbf ft)
---	----	-------------------



H01142-10

## 14.8 Checking that the brake linings of the rear brake are secured



### Warning

**Danger of accidents** Worn-out brake linings reduce the braking effect.

- Ensure that worn-out brake linings are replaced immediately. (Your authorized KTM workshop will be glad to help.)




### Warning

**Danger of accidents** Damaged brake discs reduce the braking effect.

If the brake linings are not changed in time, the brake lining carriers grind against the brake disc. As a consequence, the braking effect is greatly reduced and the brake discs are destroyed.

- Check the brake linings regularly.



- Check the brake linings for lining thickness **A**.

Minimum thickness <b>A</b>	$\geq 1 \text{ mm } (\geq 0.04 \text{ in})$
----------------------------	---

- » If it is less than the minimum thickness:
  - Change the rear brake linings.
- Check the brake linings for damage and cracking.
  - » If there is damage or cracking:
    - Change the rear brake linings.
- Check that the brake linings are secured.
  - » If the brake linings are not secured correctly:
    - Secure brake linings, replace with new parts if necessary.

## 14.9 Checking the free travel of foot brake lever



### Warning

**Danger of accidents** The brake system will fail if it overheats or is adjusted incorrectly.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

- Set the free travel on the foot brake lever in accordance with the specification.
- Ensure that the adjustment steps are performed properly. (Your authorized KTM workshop will be glad to help.)



- Disconnect spring ①.
- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel A.

Guideline

Free travel at foot brake lever	3 ... 5 mm (0.12 ... 0.2 in)
---------------------------------	------------------------------

- » If the free travel does not meet specifications:
  - Adjust the free travel of the foot brake lever. ↗ (p. 79)
- Reconnect spring ①.



## 14.10 Adjusting the free travel of the foot brake lever ↗



### Warning

**Danger of accidents** The brake system will fail if it overheats or is adjusted incorrectly.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

- Set the free travel on the foot brake lever in accordance with the specification.
- Ensure that the adjustment steps are performed properly. (Your authorized KTM workshop will be glad to help.)



- Detach spring ①.
- Release nut ② and use screw ③ to adjust the specified free travel A.

Guideline

Free travel at foot brake lever	3 ... 5 mm (0.12 ... 0.2 in)
---------------------------------	------------------------------


**i Info**

The range of adjustment is limited.  
This setting is not for adjusting the ergonomics.

- Hold screw ③ and tighten nut ②.
- Attach spring ①.



## 15.1 Removing the front wheel



### Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)
- Lift the motorcycle with the front lifting gear. (📖 p. 61)

### Main work

- Remove screw 1 and pull wheel speed sensor 2 out of the hole.
- Remove screws 3 and take off the brake caliper.
- Loosen screw 4 by several rotations.
- Loosen screws 5.
- Press on screw 4 to push the wheel spindle out of the axle clamp.
- Remove screw 4.



### Warning

**Danger of accidents** Damaged brake discs reduce the braking effect.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Hold front wheel and remove wheel spindle. Take the front wheel out of the fork.



### Info

Do not actuate the hand brake lever when the front wheel is removed.


## 15.2 Installing the front wheel



### Warning

**Danger of accidents** Oil or grease on the brake discs reduces the braking effect.


- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



- Remove spacers 1.
- Check the wheel bearing for damage and wear.
  - » If the wheel bearing is damaged or worn:
    - Change front wheel bearing. 🛠️
- Clean and grease shaft seal rings 2 and contact surfaces A of the spacers.

Long-life grease (📖 p. 123)

- Insert the spacers.



- Clean the thread of the wheel spindle and screw ③.
- Clean and lightly grease the wheel spindle.

Long-life grease (📖 p. 123)

- Position the front wheel and insert the wheel spindle.
- Mount and tighten screw ③.

Guideline

Screw, front wheel spindle	M24x1.5	45 Nm (33.2 lbf ft)
----------------------------	---------	---------------------

- Position the brake caliper, and mount and tighten screws ④.

Guideline

Screw, front brake caliper	M8x1	32 Nm (23.6 lbf ft) <b>Loctite®243™</b>
----------------------------	------	--

✓ The brake linings are correctly positioned.

- Position wheel speed sensor ⑤ in the hole.
- Mount and tighten screw ⑥.

Guideline

Screw, wheel speed sensor holder	M6	8 Nm (5.9 lbf ft)
----------------------------------	----	-------------------

- Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
- Take the motorcycle off the front lifting gear. (📖 p. 62)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)
- Operate the front brake and compress the fork a few times firmly.

✓ The fork legs straighten.

- Tighten screws ⑦.


Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	---------------------

### 15.3 Removing the rear wheel ↩

#### Preparatory work

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)



### Main work

- Remove screw ① and pull wheel speed sensor ② out of the hole.
- Remove nut ③ with washer. Take off chain adjuster ④.
- Hold the rear wheel and pull out wheel spindle ⑤ with the washer and chain adjuster ④.
- Push the rear wheel forward as far as possible and take the chain off the rear sprocket.



### Warning

**Danger of accidents** Damaged brake discs reduce the braking effect.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Pull the rear wheel back and take it out of the link fork.



### Info

Do not operate the foot brake lever when the rear wheel is removed.

## 15.4 Installing the rear wheel



### Warning

**Danger of accidents** Oil or grease on the brake discs reduces the braking effect.


- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



### Warning

**Danger of accidents** There is no braking effect to start with at the rear brake after installing the rear wheel.

- Actuate the foot brake several times before going on a ride until you can feel a firm pressure point.



### Main work

- Check the rear hub damping rubber pieces. 🛠️ (📖 p. 83)
- Remove the spacers.
- Check the wheel bearing for damage and wear.
  - » If the wheel bearing is damaged or worn:
    - Change the rear wheel bearing. 🛠️
- Clean and grease shaft seal rings ① and contact surfaces A of the spacers.


Long-life grease (📖 p. 123)

- Insert the spacers.
- Clean the thread of the wheel spindle and nut ②.
- Clean and lightly grease the wheel spindle.

Long-life grease (📖 p. 123)

- Clean the contact areas on the brake caliper bracket and link fork.

- Position the rear wheel.
  - ✓ The brake linings are correctly positioned.
- Push the rear wheel forward as far as possible and lay the chain on the rear sprocket.
- Pull the rear wheel back and mount wheel spindle ③ with the washers and chain adjusters ④.



**i Info**  
Mount left and right chain adjusters ④ in the same position.

- Mount nut ②, but do not tighten yet.
- Ensure that the chain adjusters lie flat on the screws and tighten nut ②.

**Guideline**

In order for the rear wheel to be correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to reference markings B.

Nut, rear wheel spindle	M14x1.5	100 Nm (73.8 lbf ft)
-------------------------	---------	----------------------

- Position wheel speed sensor ⑤ in the hole. Mount and tighten screw ⑥.

**Guideline**

Remaining screws, chassis	M6	9 Nm (6.6 lbf ft)
---------------------------	----	-------------------

**Finishing work**

- Check the chain tension. (📖 p. 65)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)



**15.5 Checking the rear hub damping rubber pieces 🛠️**


**i Info**  
The engine power is transmitted from the rear sprocket to the rear wheel via the 6 damping rubber pieces. They eventually wear out during operation. If the damping rubber pieces are not changed in time, the rear sprocket carrier and the rear hub will be damaged.


**Preparatory work**

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)
- Remove the rear wheel. 🛠️ (📖 p. 81)

**Main work**

- Check bearing ①.
  - » If the bearing is damaged or worn:
    - Change the rear wheel bearing. 🛠️
- Check damping rubber pieces ② of the rear hub for damage and wear.
  - » If the damping rubber pieces of the rear hub are damaged or worn:
    - Change all the damping rubber pieces of the rear hub.





### Warning

**Danger of accidents** Damaged brake discs reduce the braking effect.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Lay the rear wheel on a workbench with the rear sprocket facing upward and insert the wheel spindle in the hub.
- To check the play **A**, hold the rear wheel tight and try to rotate the rear sprocket.



### Info

Measure the play on the outside of the rear sprocket.

Play of damping rubber pieces on rear wheel	≤ 5 mm (≤ 0.2 in)
---	-------------------

- » If clearance **A** is larger than the specified value:
  - Change all the damping rubber pieces of the rear hub.

### Finishing work

- Install the rear wheel. (📖 p. 82)
- Check the chain tension. (📖 p. 65)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)

## 15.6 Checking the tire condition



### Warning

**Danger of accidents** If a tire bursts while riding, the vehicle becomes uncontrollable.

- Ensure that damaged or worn tires are replaced immediately. (Your authorized KTM workshop will be glad to help.)



### Warning

**Danger of crashing** Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

- Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.



### Warning

**Danger of accidents** Non-approved or non-recommended tires and wheels impact the handling characteristic.


- Only use tires/wheels approved by KTM with the corresponding speed index.



### Info

The type, condition, and pressure of the tires all have a major impact on the handling characteristic of the motorcycle.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.




- Check the front and rear tires for cuts, run-in objects, and other damage.
  - » If the tires have cuts, run-in objects, or other damage:
    - Change the tires. 🛠️
- Check the tread depth.

**i Info** Observe the minimum tread depth required by national law.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	--------------------

- » If the tread depth is less than the minimum tread depth:
  - Change the tires. 🛠️




- Check the tire age.

**i Info** The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.  
KTM recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

- » If the tires are more than 5 years old:
  - Change the tires. 🛠️

## 15.7 Checking tire pressure

**i Info** Low tire pressure leads to abnormal wear and overheating of the tire. Correct tire pressure ensures optimal riding comfort and maximum tire service life.



- Remove the protection cap.
- Check the tire pressure when the tires are cold.

Tire pressure when solo	
front	2.0 bar (29 psi)
rear	2.0 bar (29 psi)

Tire pressure with passenger / full payload	
front	2.0 bar (29 psi)
rear	2.2 bar (32 psi)

- » If the tire pressure does not meet specifications:
  - Correct the tire pressure.
- Mount the protection cap.

## 16.1 Removing the 12-V battery



### Warning

**Risk of injury** Battery acid and battery gases cause serious chemical burns.



- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.

### Preparatory work

- Remove the front rider's seat. (📖 p. 63)
- Remove the fuel tank cover. 🗨️ (📖 p. 67)

### Main work

- Disconnect negative cable ❶ from the 12-V battery.




- Pull back positive terminal cover ❷.
- Disconnect positive cable ❸ from the 12-V battery.
- Detach rubber strap ❹.
- Pull the 12-V battery upwards and out of the battery compartment.



### Info

Never operate the motorcycle with a discharged 12-V battery or without a 12-V battery. In both cases, electrical components and safety devices can be damaged. In this case the vehicle is no longer roadworthy.

## 16.2 Installing the 12-V battery



### Main work


- Position the 12-V battery in the battery compartment.

#### Guideline

The terminals of the battery must face upwards.

12-V battery (ETZ-9-BS) (📖 p. 115)

- Attach rubber strap ❶.
- Position positive cable ❷ and mount and tighten the screw.
- Position positive terminal cover ❸.



- Position negative cable ④ and mount and tighten the screw.

#### Finishing work

- Mount the fuel tank cover. (🔧 p. 68)
- Mount the front rider's seat. (🔧 p. 63)
- Set time and date. (🔧 p. 43)



## 16.3 Charging the 12-V battery 🛠️



### Warning

**Risk of injury** Battery acid and battery gases cause serious chemical burns.

- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.



### Note

**Environmental hazard** 12 V batteries contain environmentally hazardous materials.

- Do not dispose of 12 V batteries as household waste.
- Dispose of 12 V batteries at a collection point for used batteries.



### Note

**Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



### Info

Even when there is no load on the 12-V battery, it discharges steadily each day.

The charging level and the method of charging are very important for the service life of the 12-V battery. Rapid recharging with a high charging current shortens the service life of the battery.

If the charging current, charging voltage, or charging time is exceeded, electrolyte escapes through the safety valves. This reduces the capacity of the 12-V battery.


If the 12-V battery is discharged by repeated starting, charge the 12-V battery immediately.

If the 12-V battery is left in a discharged state for an extended period, it will become deeply discharged and sulfating occurs, thus destroying the battery.

The 12-V battery is maintenance-free. The acid level does not have to be checked.

#### Preparatory work

- Remove the front rider's seat. (🔧 p. 63)
- Remove the fuel tank cover. 🛠️ (🔧 p. 67)



### Main work

- Disconnect negative cable **1** from the 12 V battery to avoid damaging the onboard electronics.
- Remove positive terminal cover **2**.

- Connect a battery charger to the 12-V battery. Connect the battery charger to the mains connection.

EU battery charger **TecMATE Optimate PRO** (A61029974044)

### Alternative 1

USA/CA battery charger **TecMATE Optimate PRO** (A61029974144)

### Alternative 2

UK battery charger **TecMATE Optimate PRO** (A61029974244)

It is impossible to overcharge the 12-V battery using this battery charger.



### Info

After charging, the battery charger can remain on the vehicle, ensuring that the battery voltage is maintained during the maintenance charging cycle.


- Switch off the battery charger after charging and disconnect from the 12-V battery.

### Guideline

The charging current, charging voltage, and charging time must not be exceeded.

Recharge the 12-V battery regularly when the motorcycle is not being used	3 months
---	----------

- Position the negative cable and mount and tighten the screw.
- Mount positive terminal cover **2**.
- Position negative cable **1** and mount and tighten the screw.



### Finishing work

- Mount the fuel tank cover. (📖 p. 68)
- Mount the front rider's seat. (📖 p. 63)
- Set time and date. (📖 p. 43)

## 16.4 Changing the main fuse



### Warning


**Fire hazard** Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.



### Info

The main fuse protects all electrical power consumers of the vehicle. The main fuse is next to the 12-V battery.



### Preparatory work

- Remove the front rider's seat. (📖 p. 63)
- Remove the fuel tank cover. 🛠️ (📖 p. 67)

### Main work

- Remove faulty main fuse ❶.



### Info

A faulty fuse has a burned-out fuse wire ❷.



### Info

A spare fuse is located in the fuse box.

- Insert a new main fuse.

Fuse (75011088030) (📖 p. 115)



### Tip

Put a spare fuse in the fuse box so that it is available if needed.

### Finishing work

- Mount the fuel tank cover. (📖 p. 68)
- Mount the front rider's seat. (📖 p. 63)
- Set time and date.



## 16.5 Changing the ABS fuses



### Warning

**Fire hazard** Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.




### Info

Two fuses for the ABS are located under the protection cap next to the negative terminal of the 12-V battery. These fuses protect the return pump and the hydraulic unit of the ABS. The third fuse, which protects the ABS control unit, is located in the fuse box.

### Preparatory work

- Remove the front rider's seat. (📖 p. 63)
- Remove the fuel tank cover. 🛠️ (📖 p. 67)



### To change the fuse of the ABS hydraulic unit:

- Take off the protection cap and remove fuse ①.

**i Info**  
A faulty fuse has a burned-out fuse wire ①.

**! Warning**  
**Fire hazard** Incorrect fuses overload the electrical system.


- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.

- Insert the spare fuse with the correct rating.

Fuse (75011088010) (📖 p. 115)

**i Tip**  
Insert spare fuse ② in the fuse box so that it is available if needed.

- Mount the protection cap.



### To change the fuse of the ABS return pump:

- Take off the protection cap and remove fuse ②.

**i Info**  
A faulty fuse has a burned-out fuse wire ①.

**! Warning**  
**Fire hazard** Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.

- Insert the spare fuse with the correct rating.

Fuse (90111088025) (📖 p. 115)

**i Tip**  
Insert spare fuse ③ in the fuse box so that it is available if needed.

- Mount the protection cap.


### Finishing work

- Mount the fuel tank cover. (📖 p. 68)
- Mount the front rider's seat. (📖 p. 63)

## 16.6 Changing the fuses of individual electrical power consumers

### **i** Info

The fuse box with the main fuse and fuses of the individual power consumers is located next to the positive terminal of the 12-V battery.



### Preparatory work

- Remove the front rider's seat. (📖 p. 63)
- Remove the fuel tank cover. 🛠️ (📖 p. 67)

### Main work

- Open fuse box cover.
- Remove the faulty fuse.

### Guideline

Fuse 1 - not assigned
Fuse 2 - 10 A - combination instrument, fuel pump
Fuse 3 - 10 A - power relay
Fuse 4 - 15 A - ignition coil, horn, starter relay
Fuse 5 - 20 A - radiator fan
Fuse 6 - 10 A - brake light, turn signal, high beam, low beam, position light, tail light, license plate lamp
Fuse 7 - 10 A - ABS control unit, combination instrument, diagnostics connector
Fuse 8 - 10 A - emergency OFF switch
Fuse 9 - 10 A - permanent positive for auxiliary equipment (ACC1)
Fuse 10 - 10 A - ignition positive for auxiliary equipment (ACC2)
Fuse SPARE - 10 A/15 A/20 A/30 A - spare fuses

### **i** Info

A faulty fuse has a burned-out fuse wire **A**.



### Warning

**Fire hazard** Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.

- Insert the spare fuse with the correct rating.

Fuse (75011088010) (📖 p. 115)
Fuse (75011088015) (📖 p. 115)
Fuse (75011088020) (📖 p. 115)
Fuse (75011088030) (📖 p. 115)

### **i** Tip


Put a spare fuse in the fuse box so that it is available if needed.

- Check the function of the electrical power consumer.
- Close the fuse box cover.

## Finishing work

- Mount the fuel tank cover. (📖 p. 68)
- Mount the front rider's seat. (📖 p. 63)

## 16.7 Checking the headlight setting



400726-10

- Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first marking.

### Guideline

Distance <b>B</b>	5 cm (2 in)
-------------------	-------------

- Position the vehicle upright at distance **A** from the wall and switch on the low beam.

### Guideline

Distance <b>A</b>	5 m (16 ft)
-------------------	-------------


- The rider now mounts the motorcycle with luggage and passenger if applicable.
- Check the headlight setting.

The light-dark boundary must be exactly on the lower marking when the motorcycle is ready to be operated with the rider mounted along with any luggage and a passenger if applicable.

- » If the boundary between light and dark does not meet specifications:

- Adjust the headlight range. (📖 p. 92)

## 16.8 Adjusting the headlight range



S05263-10

### Main work

- Adjust the headlights' range by turning screw **1** on the bottom of the headlight.

### Guideline

For a motorcycle with a rider, and any luggage and/or passenger, the light/dark boundary must be exactly on the lower marking (applied in: Checking the headlight setting).




### Info

Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.

### Finishing work


- Check the headlight setting. (📖 p. 92)

## 16.9 Diagnostics connector



Diagnostics connector **1** is located under the front rider's seat.

## 16.10 ACC1 front



### Installation location

- Power supplies ACC1 **1** front are located under the coolant compensating tank.

### **i** Info


The power supplies are protected by a fuse; however, this fuse also protects other electrical power consumers. The maximum continuous load is therefore significantly lower than the value of the fuse.

Do not use a stronger fuse.

The power supply ACC1 is switched to permanent positive; connected power consumers are permanently supplied with current, regardless of ignition.

The power supply ACC2 is switched to ignition plus; connected power consumers are only supplied with power when the ignition is switched on.

## 16.11 ACC1 and ACC2 rear



### Installation location

- Power supplies ACC1 **1** and ACC2 **2** rear are located under the seat.

### **i** Info

The cable insulation label indicates the type of power supply.

### **i** Info


The power supplies are protected by a fuse; however, this fuse also protects other electrical power consumers. The maximum continuous load is therefore significantly lower than the value of the fuse.

Do not use a stronger fuse.

The power supply ACC1 is switched to permanent positive; connected power consumers are permanently supplied with current, regardless of ignition.

The power supply ACC2 is switched to ignition plus; connected power consumers are only supplied with power when the ignition is switched on.


## 17.1 Cooling system



Water pump ① in the engine ensures forced circulation of the coolant.

The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ②. Heat expansion causes excess coolant to flow into compensating tank ③. When the temperature falls, this surplus coolant is sucked back into the cooling system. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

110 °C (230 °F)



The coolant is cooled by the air stream and radiator fan ④, which is activated depending on the temperature.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

## 17.2 Checking the coolant level in the compensating tank



### Warning

**Danger of scalding** During motorcycle operation, the coolant gets hot and is under pressure.


- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



### Warning

**Danger of poisoning** Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



**Condition**

The engine is cold.  
The radiator is completely full.

- Stand the motorcycle upright on a horizontal surface.
- Check the coolant level in the compensating tank ①.

The coolant level must be between **MIN** and **MAX**.

- » If there is no coolant in the compensating tank:
  - Check the cooling system for leaks. 🛠️

**i Info**

Do not start up the motorcycle!

- Fill/bleed the cooling system. 🛠️ (📖 p. 97)
- » If the coolant in the compensating tank is not at the required level, but the tank is not empty:
  - Correct the coolant level in the compensating tank.

**17.3 Checking the antifreeze and coolant level**



**Warning**

**Danger of scalding** During motorcycle operation, the coolant gets hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



**Warning**

**Danger of poisoning** Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

**Condition**

The engine is cold.

**Preparatory work**


- Remove the right side cover. 🛠️ (📖 p. 70)


**Main work**

- Stand the motorcycle upright on a horizontal surface.
- Take off cap ① of the compensating tank.
- Check the antifreeze in the coolant.

-25 ... -45 °C (-13 ... -49 °F)

- » If the antifreeze in the coolant does not match the specified value:
  - Correct the antifreeze in the coolant.
- Check the coolant level in the compensating tank.





The coolant level must be between **MIN** and **MAX**.

- » If the coolant level does not match the specified value:
  - Correct the coolant level.

Coolant (📖 p. 121)

- Mount the cap of the compensating tank.
- Take off radiator cap ②.
- Check the antifreeze in the coolant.

–25 ... -45 °C (-13 ... -49 °F)

- » If the antifreeze in the coolant does not match the specified value:
  - Correct the antifreeze in the coolant.
- Check the coolant level in the radiator.

The radiator must be filled completely.

- » If the coolant level does not match the specified value:
  - Check the coolant level and the reason for the loss.

Coolant (📖 p. 121)

- » If you had to add more coolant than the specified amount:
  - > 0.20 l (> 0.21 qt.)
    - Fill/bleed the cooling system. 🛠️ (📖 p. 97)
- Mount the radiator cap.

#### Finishing work

- Install the right side cover. 🛠️ (📖 p. 70)

## 17.4 Draining the coolant 🛠️



### Warning

**Danger of scalding** During motorcycle operation, the coolant gets hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



### Warning

**Danger of poisoning** Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

#### Condition

The engine is cold.

#### Preparatory work

- Remove the left side cover. 🛠️ (📖 p. 69)
- Remove the right side cover. 🛠️ (📖 p. 70)



### Main work

- Position the motorcycle upright.
- Position an appropriate container under the engine.
- Remove screw ❶.
- Take off the radiator cap.
- Completely drain the coolant.
- Mount and tighten screw ❶ with a new seal ring.

### Guideline

Screw plug, water pump drain hole	M6	11 Nm (8.1 lbf ft) <b>Loctite®243™</b>
-----------------------------------	----	---




## 17.5 Filling/bleeding the cooling system ↴



### Warning


**Danger of poisoning** Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



### Main work

- Remove radiator cap ❶.



- Loosen bleeder screw ❷.

### Guideline

3 turns
---------

- Tilt the vehicle slightly to the right.
- Pour in the coolant until it emerges without bubbles at the bleeder screw, and then mount and tighten the bleeder screw immediately.

Coolant (📖 p. 121)
--------------------


- Completely fill the radiator with coolant. Mount the radiator cap.
- Rest the vehicle on the side stand.



## Danger

**Danger of poisoning** Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



- Start the engine and allow it to warm up.
- Stop the engine and allow it to cool down.
- When the engine is cool, check the coolant level in the radiator and, if necessary, add coolant.
- Remove cap ③ of the compensating tank and top up the coolant level up to the **MAX** marking.
- Mount the cap of the compensating tank.

## Finishing work

- Install the left side cover. 🛠️ (📖 p. 69)
- Install the right side cover. 🛠️ (📖 p. 70)

## 17.6 Changing the coolant



### Warning

**Danger of scalding** During motorcycle operation, the coolant gets hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



### Warning

**Danger of poisoning** Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

## Condition

The engine is cold.


## Preparatory work

- Remove the right side cover. 🛠️ (📖 p. 70)
- Remove the left side cover. 🛠️ (📖 p. 69)



### Main work


- Position the motorcycle upright.
- Place an appropriate container under the engine.
- Remove screw ①.



- Remove radiator cap ②.
- Completely drain the coolant.
- Mount and tighten screw ① with a new seal ring.

#### Guideline

Screw plug, water pump drain hole	M6	11 Nm (8.1 lbf ft) <b>Loctite®243™</b>
-----------------------------------	----	---



- Loosen bleeder screw ③.

#### Guideline

3 turns
---------

- Tilt the vehicle slightly to the right.
- Pour in the coolant until it emerges without bubbles at the bleeder screw, and then mount and tighten the bleeder screw immediately.

Coolant (📖 p. 121)
--------------------


- Completely fill the radiator with coolant. Mount the radiator cap.
- Rest the vehicle on the side stand.



### Danger





**Danger of poisoning** Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



- Start the engine and allow it to warm up.
- Stop the engine and allow it to cool down.
- When the engine is cool, check the coolant level in the radiator and, if necessary, add coolant.
- Remove cap ④ of the compensating tank and top up the coolant level up to the **MAX** marking.
- Mount the cap of the compensating tank.

## Finishing work

- Install the left side cover.   p. 69)
- Install the right side cover.   p. 70)




18.1 Checking the clutch lever play

Note

**Clutch damage** If there is no free travel by the clutch lever, the clutch will begin to slip.

- Check the free travel of the clutch lever each time before using the motorcycle.
- Adjust the free travel of the clutch lever when necessary in accordance with the specification.



- Check the clutch lever for smooth operation.
- Move the handlebar to the straight-ahead position.
- Pull the clutch lever until resistance is perceptible, and determine the play in the clutch lever **A**.

Clutch lever play <b>A</b>	1 ... 3 mm (0.04 ... 0.12 in)
----------------------------	-------------------------------


- » If the clutch lever play does not meet the specified value:
  - Adjust play in the clutch lever. 🛠️ (p. 101)
- Move the handlebar to and fro over the entire steering range.

The clutch lever play must not change.

- » If the clutch lever play changes:
  - Check the routing of the clutch cable.



18.2 Adjusting play in the clutch lever 🛠️




- Move the handlebar to the straight-ahead position.
- Push back sleeve **1**.
- Loosen lock nut **2**.
- Adjust the play in the clutch level **A** by turning adjusting screw **3**.


Guideline

Clutch lever play <b>A</b>	1 ... 3 mm (0.04 ... 0.12 in)
----------------------------	-------------------------------

- Tighten lock nut **2**.
- Position bellows **1**.



## 19.1 Checking the engine oil level



### Condition

The engine is at operating temperature.

### Preparatory work

- Stand the motorcycle upright on a horizontal surface.

### Main work

- Check the engine oil level.



### Info

After switching off the engine, wait one minute before checking the level.

The engine oil must be between the **A** and **B** markings .

- » When the engine oil level is below the **A** marking:
  - Add engine oil. (📖 p. 104)
- » When the engine oil level is above the **B** marking:
  - Correct the engine oil level.

## 19.2 Changing the engine oil and oil filter, cleaning the oil screens



### Warning

**Danger of scalding** Engine and gear oil get hot when the motorcycle is operated.

- Wear suitable protective clothing and safety gloves.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



### Note

**Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



### Info


Drain the engine oil while the engine is at operating temperature.



### Preparatory work

- Stand the motorcycle on a level surface using the side stand.

### Main work

- Remove screws **1** and take off the cover.





S05267-10

- Position an appropriate container under the engine.
- Remove oil drain plug **2** with the O-ring.
- Remove oil screen **3** with the O-ring.
- Remove screw plug **4** with oil screen **5**.
- Allow the engine oil to drain completely.
- Thoroughly clean the oil drain plugs and oil screens.
- Position oil screen **3** and mount and tighten oil drain plug **2** with the O-ring.


Guideline

Oil drain plug	M24x1.5	13 Nm (9.6 lbf ft)
----------------	---------	--------------------

- Mount and tighten screw plug **4** with oil screen **5** and the O-ring.


Guideline

Oil screen screw plug, small	M17x1.5	11 Nm (8.1 lbf ft)
------------------------------	---------	--------------------



S05268-10

- Remove screws **6**. Take off oil filter cover **7** with the O-ring.
- Pull oil filter **8** out of the oil filter housing.
- Allow the engine oil to drain completely.
- Thoroughly clean the parts and the sealing surface.



S05269-10


- Insert new oil filter **8**.
- Oil the O-ring of the oil filter cover. Mount oil filter cover **7**.
- Mount and tighten the screws.

Guideline

Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)
-------------------------	----	--------------------

**i** Info

Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



S05270-10

- Remove filler plug **9** with the O-ring, and fill up with engine oil.

Engine oil	1.7 l (1.8 qt.)	Engine oil (SAE 15W/50) (p. 121)
------------	-----------------	----------------------------------


- Mount and tighten the filler plug together with the O-ring.



### Danger

**Danger of poisoning** Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.



- Start the engine and check it for leaks.
- Position the cover, mount and tighten screws **1**.

### Guideline

Remaining screws, chassis	M6	9 Nm (6.6 lbf ft)
---------------------------	----	-------------------

### Finishing work


- Check the engine oil level. (📖 p. 102)

## 19.3 Adding engine oil



### Info

Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



### Main work

- Remove filler plug **1** with the O-ring, and fill up with engine oil.

Engine oil (SAE 15W/50) (📖 p. 121)



### Info

In order to achieve optimal engine oil performance, it is not advisable to mix different engine oils. KTM recommends changing the engine oil.

- Mount and tighten the filler plug together with the O-ring.



### Danger

**Danger of poisoning** Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

- Start the engine and check for leaks.

### Finishing work

- Check the engine oil level. (📖 p. 102)

**20.1 Cleaning the motorcycle**

**Note**

**Material damage** Components become damaged or destroyed if a pressure cleaner is used incorrectly.

The high pressure forces water into the electrical components, connectors, throttle cables, and bearings, etc. Pressure which is too high causes malfunctions and destroys components.

- Do not direct the water jet directly on to electrical components, connectors, throttle cables or bearings.
- Maintain a minimum distance between the nozzle of the pressure cleaner and the component.  
Minimum clearance 60 cm (23.6 in)



**Note**


**Environmental hazard** Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



**Info**

Clean the motorcycle regularly to maintain its value and appearance over a long period. Avoid direct sunshine when cleaning the motorcycle.



- Close off exhaust system to keep water from entering.
- Remove loose dirt first with a soft jet of water.
- Spray the heavily soiled parts with a normal commercial motorcycle cleaner and clean using a brush.

Motorcycle cleaner (📖 p. 123)



**Info**

Use warm water containing normal motorcycle cleaner and a soft sponge. Never apply motorcycle cleaner to a dry motorcycle; always rinse the vehicle with water first. Clean the motorcycle with cold water if it has been used on salted roads. Warm water enhances the corrosive effects of salt.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the closure of the exhaust system.



**Warning**

**Danger of accidents** Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.

- After cleaning, ride the vehicle a short distance until the engine warms up.



**Info**

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

- Push back the sleeves of the handlebar controls to allow any water that has penetrated to evaporate.
- After the motorcycle has cooled down, lubricate all moving parts and pivot points.
- Clean the chain. (📖 p. 64)
- Treat bare metal (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber (📖 p. 123)

- Treat all painted parts with a mild paint care product.

Shine spray for paint, plastic and chromium (📖 p. 123)

**i Info**

Do not polish parts that were matte when delivered as this would strongly impair the material quality.

- Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces (📖 p. 123)

- Lubricate the ignition and steering lock.


Universal oil spray (📖 p. 123)

## 20.2 Checks and maintenance steps for winter operation

**i Info**

If you use the motorcycle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.

Clean the motorcycle with cold water if it has been used on salted roads. Warm water enhances the corrosive effects of salt.



- Clean the motorcycle. (📖 p. 105)
- Clean the brakes.

**i Info**

After **EVERY** trip on salted roads, thoroughly clean the motorcycle and, in particular, the brake calipers and brake linings, after they have cooled down and without removing them, with cold water and dry carefully.

- Treat the engine, the link fork, and all other bare or zinc-plated parts (except the brake discs) with a wax-based corrosion inhibitor.

**i Info**

Corrosion inhibitor must not come in contact with the brake discs as this would greatly reduce the braking force.


- Clean the chain. (📖 p. 64)

## 21.1 Storage

**i** Info

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed.

Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.

Fuel additive (📖 p. 123)
--------------------------

- Refuel. (📖 p. 55)

**i** Tip

Fill the fuel tank completely as specified, using fuel with the lowest possible ethanol content.

- Clean the motorcycle. (📖 p. 105)
- Change the engine oil and the oil filter, clean the oil screens. 🛠️ (📖 p. 102)
- Check the antifreeze and coolant level. (📖 p. 95)
- Check tire pressure. (📖 p. 85)
- Remove the 12-V battery. 🛠️ (📖 p. 86)
- Charge the 12-V battery. 🛠️ (📖 p. 87)

## Guideline

Storage temperature of the 12-V battery without direct sunlight	0 ... 35 °C (32 ... 95 °F)
---	----------------------------

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

**i** Info


KTM recommends jacking up the motorcycle.

- Raise the motorcycle with the rear lifting gear. (📖 p. 61)
- Lift the motorcycle with the front lifting gear. (📖 p. 61)
- Cover the motorcycle with a tarp or cover that is permeable to air.

**i** Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion. Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

## 21.2 Preparing for use after storage



- Take the motorcycle off the front lifting gear. (📖 p. 62)
- Remove the rear of the motorcycle from the lifting gear. (📖 p. 61)
- Install the 12-V battery. 🛠️ (📖 p. 86)
- Set time and date. (📖 p. 43)
- Perform checks and maintenance measures when preparing for use. (📖 p. 48)
- Take a test ride.

Faults	Possible cause	Action
The engine does not turn when the start button is pressed	Operating error	– Carry out start procedure. (📖 p. 48)
	12-V battery discharged	– Charge the 12-V battery. 🛠️ (📖 p. 87)
	Fuse <b>1</b> , <b>3</b> , <b>4</b> , or <b>7</b> is blown	– Change the fuses of individual electrical power consumers. (📖 p. 91)
	No ground connection present on the starter motor	– Check the ground connection.
Engine turns only if the clutch lever is drawn	The vehicle is in gear	– Shift the transmission into neutral.
	The vehicle is in gear and the side stand is folded out	– Shift the transmission into neutral.
The engine turns but does not start	Operating error	– Carry out start procedure. (📖 p. 48)
	Quick release coupling not joined	– Join the quick release coupling.
	Malfunction in the electronic fuel injection	– Read out the fault memory using the KTM diagnostics tool. 🛠️
Engine has too little power	Air filter is very dirty	– Change the air filter.
	Fuel filter is very dirty	– Check the fuel pressure. 🛠️
	Malfunction in the electronic fuel injection	– Read out the fault memory using the KTM diagnostics tool. 🛠️
Engine overheats	Too little coolant in cooling system	– Check the cooling system for leakage. – Check the coolant level in the compensating tank. (📖 p. 94)
	Radiator fins very dirty	– Clean the radiator fins.
	Foam formation in cooling system	– Drain the coolant. 🛠️ (📖 p. 96) – Fill/bleed the cooling system. 🛠️ (📖 p. 97)
	Thermostat defective	– Check the thermostat. 🛠️
	Fuse <b>5</b> blown	– Change the fuses of individual electrical power consumers. (📖 p. 91)
	Defect in radiator fan system	– Check the radiator fan system. 🛠️
Malfunction indicator lamp lights up red	Malfunction in the electronic fuel injection	– Read out the fault memory using the KTM diagnostics tool. 🛠️
Engine dies during the trip	Lack of fuel	– Refuel. (📖 p. 55)
	Fuse <b>1</b> , <b>3</b> , <b>4</b> , or <b>7</b> is blown	– Change the fuses of individual electrical power consumers. (📖 p. 91)
The ABS warning lamp lights up	ABS fuse blown	– Change the ABS fuses. (📖 p. 89)
	Large difference in wheel speeds of the front and rear wheels	– Stop the vehicle, switch off the ignition, and start it again.
	Malfunction in ABS	– Read out the fault memory using the KTM diagnostics tool. 🛠️
High oil consumption	Engine vent hose bent	– Route the vent hose without bends or change it if necessary.
	Engine oil level too high	– Check the engine oil level. (📖 p. 102)
	Engine oil too thin (low viscosity)	– Change the engine oil and the oil filter, clean the oil screens. 🛠️ (📖 p. 102)
Headlight and position light are not functioning	Fuse <b>6</b> blown	– Change the fuses of individual electrical power consumers. (📖 p. 91)
Turn signal, brake light, and horn are not functional	Fuse <b>6</b> blown	– Change the fuses of individual electrical power consumers. (📖 p. 91)

Faults	Possible cause	Action
Time is not (correctly) displayed	Fuse <b>7</b> is blown	<ul style="list-style-type: none"> <li>– Change the fuses of individual electrical power consumers. (🔧 p. 91)</li> <li>– Set time and date. (🔧 p. 43)</li> </ul>
12 V battery discharged	Ignition was not switched off when vehicle was parked	– Charge the 12-V battery. 🛡️ (🔧 p. 87)
	The 12-V battery is not being charged by the alternator	<ul style="list-style-type: none"> <li>– Check the charging voltage. 🛡️</li> <li>– Check the open-circuit current. 🛡️</li> </ul>
The combination instrument shows nothing on the display	Fuse <b>7</b> is blown	<ul style="list-style-type: none"> <li>– Change the fuses of individual electrical power consumers. (🔧 p. 91)</li> <li>– Set time and date. (🔧 p. 43)</li> </ul>
Speedometer in combination instrument not functioning	Speedometer wiring harness is damaged or plug-in connector is oxidized	– Check the wiring harness and plug-in connector.

**23.1 Engine**

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	373 cm <sup>3</sup> (22.76 cu in)
Stroke	60 mm (2.36 in)
Bore	89 mm (3.5 in)
Compression ratio	12.54:1
Control	DOHC, four valves controlled via cam lever, chain drive
Intake valve diameter	36 mm (1.42 in)
Exhaust valve diameter	29 mm (1.14 in)
Valve clearance, intake, cold	0.10 ... 0.15 mm (0.0039 ... 0.0059 in)
Valve clearance, exhaust, cold	0.15 ... 0.20 mm (0.0059 ... 0.0079 in)
Crankshaft bearing	2 slide bearings
Conrod bearing	Sleeve bearing
Pistons	Forged light alloy
Piston rings	1 compression ring, 1 tapered compression piston ring, 1 oil scraper ring
Engine lubrication	Pressure circulation lubrication with 2 trochoidal pumps
Primary transmission	30:80
Clutch	Slipper clutch in oil bath/mechanically operated
Transmission	6-gear transmission, claw shifted
Transmission ratio	
1st gear	12:32
2nd gear	14:26
3rd gear	19:27
4th gear	21:24
5th gear	23:22
6th gear	25:21
Mixture preparation	Electronic fuel injection
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment
Alternator	12 V, 230 W
Spark plug	<b>BOSCHVR6NEU</b>
Spark plug electrode gap	1 mm (0.04 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Idle speed	1,400 ± 50 rpm
Starting aid	Starter motor

## 23.2 Engine tightening torques

Oil nozzle	M5	4 Nm (3 lbf ft)	<b>Loctite®243™</b>
Screw, crankshaft speed sensor	M5	5 Nm (3.7 lbf ft)	<b>Loctite®243™</b>
Screw, gear position sensor	M5	5 Nm (3.7 lbf ft)	<b>Loctite®243™</b>
Screw, retaining bracket, stator cable	M5	7 Nm (5.2 lbf ft)	<b>Loctite®243™</b>
Screw, stator	M5	8 Nm (5.9 lbf ft)	<b>Loctite®243™</b>
Nut, water pump impeller	M6	8 Nm (5.9 lbf ft)	<b>Loctite®243™</b>
Oil nozzle	M6	5 Nm (3.7 lbf ft)	<b>Loctite®243™</b>
Screw plug, water pump drain hole	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, alternator cover	M6	11 Nm (8.1 lbf ft)	
Screw, bearing retainer	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, camshaft bearing support	M6	10 Nm (7.4 lbf ft)	
Screw, camshaft, decompression shaft	M6	10 Nm (7.4 lbf ft)	<b>Loctite®243™</b>
Screw, chain securing guide	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, clutch cable retaining bracket	M6	6 Nm (4.4 lbf ft)	<b>Loctite®243™</b>
Screw, clutch cover	M6	11 Nm (8.1 lbf ft)	
Screw, clutch spring	M6	10 Nm (7.4 lbf ft)	
Screw, cylinder head	M6	11 Nm (8.1 lbf ft)	
Screw, engine case	M6x35	11 Nm (8.1 lbf ft)	
Screw, engine case	M6x75	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, engine vent plate	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, freewheel gear retaining bracket	M6	10 Nm (7.4 lbf ft)	<b>Loctite®243™</b>
Screw, lock washer, engine sprocket	M6	12 Nm (8.9 lbf ft)	<b>Loctite®243™</b>
Screw, locking lever	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)	
Screw, oil pump	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, retaining bracket	M6	11 Nm (8.1 lbf ft)	<b>Loctite®243™</b>
Screw, retaining bracket, radial shaft seal ring, clutch cover	M6	12 Nm (8.9 lbf ft)	<b>Loctite®243™</b>

Screw, shift drum locating unit	M6	11 Nm (8.1 lbf ft) <b>Loctite®243™</b>
Screw, starter motor	M6	11 Nm (8.1 lbf ft)
Screw, timing chain tensioner	M6	11 Nm (8.1 lbf ft)
Screw, timing chain tensioning rail	M6	11 Nm (8.1 lbf ft) <b>Loctite®243™</b>
Screw, unlocking for timing chain tensioner	M6	7 Nm (5.2 lbf ft)
Screw, valve cover	M6	11 Nm (8.1 lbf ft)
Screw, water pump cover	M6	11 Nm (8.1 lbf ft)
Nut, exhaust flange	M8	21 Nm (15.5 lbf ft)
Screw plug	M8	10 Nm (7.4 lbf ft)
Screw, balancer shaft gear wheel	M8	39 Nm (28.8 lbf ft) <b>Loctite®243™</b>
Screw, spring thrust bearing of the shift shaft	M8	20 Nm (14.8 lbf ft) <b>Loctite®243™</b>
Stud, exhaust flange	M8	21 Nm (15.5 lbf ft)
Screw, conrod bearing	M8.5x0.75	1st stage 31.5 Nm (23.23 lbf ft) 2nd stage 41 Nm (30.2 lbf ft) 75°
Coolant temperature sensor	M10	13 Nm (9.6 lbf ft)
Oil pressure sensor	M10	13 Nm (9.6 lbf ft)
Screw, camshaft gear wheel	M10	35 Nm (25.8 lbf ft) <b>Loctite®243™</b>
Screw, cylinder head	M10	1st stage 30 Nm (22.1 lbf ft) 2nd stage 64 Nm (47.2 lbf ft) Thread is oiled, head flat is greased
Screw, rotor	M10	105 Nm (77.4 lbf ft) <b>Loctite®243™</b>
Screw plug, cam lever axis	M10x1	11 Nm (8.1 lbf ft) <b>Loctite®243™</b>
Spark plug	M12	20 Nm (14.8 lbf ft)
Nut, inner clutch hub	M14LHx1.5	72 Nm (53.1 lbf ft) <b>Loctite®243™</b>
Nut, primary gear wheel/timing chain sprocket	M16x1.5	150 Nm (110.6 lbf ft) <b>Loctite®243™</b>
Oil screen screw plug, small	M17x1.5	11 Nm (8.1 lbf ft)
Screw plug, alternator cover	M18x1.5	9 Nm (6.6 lbf ft)
Oil drain plug	M24x1.5	13 Nm (9.6 lbf ft)
Screw plug, alternator cover	M24x1.5	6 Nm (4.4 lbf ft)
Nut, drive gear wheel for balancer shaft	M28	65 Nm (47.9 lbf ft) <b>Loctite®243™</b>

## 23.3 Capacities

### 23.3.1 Engine oil

Engine oil	1.7 l (1.8 qt.)	Engine oil (SAE 15W/50) (📖 p. 121)
------------	-----------------	---------------------------------------

### 23.3.2 Coolant

Coolant	1.2 l (1.3 qt.)	Coolant (📖 p. 121)
---------	-----------------	--------------------

### 23.3.3 Fuel

Total fuel tank capacity, approx.	14 l (3.7 US gal)	Super unleaded (ROZ 95) (📖 p. 122)
-----------------------------------	-------------------	---------------------------------------

Fuel reserve, approx.	3.5 l (3.7 qt.)	
-----------------------	-----------------	--

## 23.4 Chassis

Frame	Lattice frame of steel tubes, powder-coated	
Fork	<b>WP APEX 3343</b>	
Shock absorber	<b>WP APEX 3446</b>	
Brake system		
front	Disc brake with 4-piston brake caliper	
rear	Disc brake with single-pot brake caliper, floating	
Suspension travel		
front	120 mm (4.72 in)	
rear	150 mm (5.91 in)	
Brake discs - diameter		
front	320 mm (12.6 in)	
rear	230 mm (9.06 in)	
Brake discs - wear limit		
front	4.5 mm (0.177 in)	
rear	3.6 mm (0.142 in)	
Tire pressure when solo		
front	2.0 bar (29 psi)	
rear	2.0 bar (29 psi)	
Tire pressure with passenger / full payload		
front	2.0 bar (29 psi)	
rear	2.2 bar (32 psi)	
Secondary ratio	15:44	
	<div style="border: 1px solid black; padding: 5px;"> <p><b>i Info</b> Modifications to the transmission ratio are not permitted and can lead to malfunctions.</p> </div>	
Chain	5/8 x 1/4" (520) X-ring	
Steering head angle	66.5°	
Wheelbase	1,340 ± 15 mm (52.76 ± 0.59 in)	
Seat height, unloaded	824 mm (32.44 in)	

Ground clearance, unloaded	178 mm (7.01 in)
Weight without fuel, approx.	154 kg (340 lb.)
Maximum permissible front axle load	135 kg (298 lb.)
Maximum permissible rear axle load	230 kg (507 lb.)
Maximum permissible overall weight	355 kg (783 lb.)

### 23.5 Electrical system

12-V battery	ETZ-9-BS	Battery voltage: 12 V Nominal capacity: 8 Ah Maintenance-free
Fuse	75011088010	10 A
Fuse	75011088015	15 A
Fuse	75011088020	20 A
Fuse	90111088025	25 A
Fuse	75011088030	30 A

Low beam/high beam	LED
Daytime running light/position light	LED
Combination instrument lighting and indicator lamps	LED
Turn signal	LED
Brake light	LED
Tail light	LED
License plate lamp	LED

### 23.6 Tires

Front tire	Rear tire
<b>110/70 R 17 M/C 54V TL</b> Continental ContiRoad	<b>150/60 R 17 M/C 66V TL</b> Continental ContiRoad
The tires specified represent one of the possible series production tires. For alternative manufacturers, if any, contact an authorized dealer or qualified tire dealership. If local road approval regulations apply, these and the respective technical specifications must be observed. Additional information is available in the Service section under: KTM.COM	

### 23.7 Fork

Fork article number	F201321010
Fork	<b>WP APEX 3343</b>
Fork length	747 mm (29.41 in)
Compression damping	
Standard	15 clicks
Rebound damping	
Standard	15 clicks
Spring rate	
Medium (standard)	6 N/mm (34 lb/in)
Spring length with preload spacer(s)	358 mm (14.09 in)
Fork oil per fork leg	460 ± 5 ml (15.55 ± 0.17 fl. oz.)
Fork oil (SAE 5) (📖 p. 122)	

## 23.8 Shock absorber

Shock absorber article number	01.58.5U.11	
Shock absorber	<b>WP APEX 3446</b>	
Spring preload		
Standard	3 clicks	
Rebound damping		
Standard	3 clicks	
Static sag	15 mm (0.59 in)	
Riding sag	41 mm (1.61 in)	
Spring rate		
Medium (standard)	120 N/mm (685 lb/in)	
Spring length	177 mm (6.97 in)	
Inbuilt length	307 mm (12.09 in)	
Gas pressure	16 bar (232 psi)	
Shock absorber oil	Shock absorber fluid (SAE 2.5) (50180751S1) (📖 p. 122)	

## 23.9 Chassis tightening torques

Exhaust clamp	-	19 Nm (14 lbf ft)	
Remaining screws, chassis	M4	4 Nm (3 lbf ft)	
Screw, engine control unit	M4	3 Nm (2.2 lbf ft)	
Nut, chain guard	M5	7 Nm (5.2 lbf ft)	
Nut, reflector on retaining plate	M5	7 Nm (5.2 lbf ft)	
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)	
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)	
Remaining screws, trim	M5	4 Nm (3 lbf ft)	
Screw, ABS hose clamp	M5	6 Nm (4.4 lbf ft)	
Screw, anti-rotation lock, handlebar stub	M5	4 Nm (3 lbf ft)	
Screw, battery compartment	M5	4 Nm (3 lbf ft)	
Screw, cover in front of battery compartment	M5	4 Nm (3 lbf ft)	
Screw, fuel tank cover	M5	5 Nm (3.7 lbf ft)	
Screw, fuel tank cover	M5	5 Nm (3.7 lbf ft)	
Screw, retaining plate on license plate holder	M5	4 Nm (3 lbf ft)	
Screw, side stand sensor	M5	5 Nm (3.7 lbf ft)	<b>Loctite®243™</b>
Screw, tail end lower part	M5	4 Nm (3 lbf ft)	
Screw, tilt sensor	M5	6 Nm (4.4 lbf ft)	<b>Loctite®243™</b>
Screw, wheel speed sensor wheel	M5	7 Nm (5.2 lbf ft)	<b>Loctite®243™</b>
ABS fitting	M6	7 Nm (5.2 lbf ft)	<b>Loctite®243™</b>
Battery compartment cover lock	M6	6 Nm (4.4 lbf ft)	

Nut, license plate holder	M6	8.5 Nm (6.27 lbf ft)
Nut, radiator	M6	5 Nm (3.7 lbf ft)
Nut, tail light	M6	7 Nm (5.2 lbf ft)
Remaining nuts, chassis	M6	15 Nm (11.1 lbf ft)
Remaining screws, chassis	M6	9 Nm (6.6 lbf ft)
Remaining screws, trim	M6	6 Nm (4.4 lbf ft)
Screw, ABS module on ABS module retaining bracket	M6	7 Nm (5.2 lbf ft)
Screw, air filter box cover	M6	3 Nm (2.2 lbf ft)
Screw, air filter box, on frame	M6	6 Nm (4.4 lbf ft)
Screw, battery compartment	M6	6 Nm (4.4 lbf ft)
Screw, brake cylinder	M6	8 Nm (5.9 lbf ft)
		<b>Loctite®243™</b>
Screw, brake fluid reservoir for rear brake	M6	8 Nm (5.9 lbf ft)
Screw, brake hose clamp	M6	6 Nm (4.4 lbf ft)
Screw, brake line guide on bottom triple clamp	M6	7 Nm (5.2 lbf ft)
		<b>Loctite®243™</b>
Screw, chain guard	M6	3 Nm (2.2 lbf ft)
Screw, chain sliding guard	M6	7 Nm (5.2 lbf ft)
Screw, compensating tank	M6	9 Nm (6.6 lbf ft)
Screw, cross connector, seat support	M6	5 Nm (3.7 lbf ft)
Screw, damping rubber for radiator	M6	6 Nm (4.4 lbf ft)
Screw, engine control unit retaining bracket	M6	6 Nm (4.4 lbf ft)
Screw, engine sprocket cover	M6	8 Nm (5.9 lbf ft)
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)
		<b>Loctite®243™</b>
Screw, front fairing	M6	7 Nm (5.2 lbf ft)
Screw, front fairing structure on headlight bracket	M6	6 Nm (4.4 lbf ft)
Screw, front fender on axle clamp	M6	7 Nm (5.2 lbf ft)
Screw, front seat fixing	M6	6 Nm (4.4 lbf ft)
Screw, front spoiler	M6	7 Nm (5.2 lbf ft)
Screw, front spoiler retaining bracket, rear	M6	6 Nm (4.4 lbf ft)
Screw, front spoiler retaining bracket, rear, on engine	M6	9 Nm (6.6 lbf ft)
Screw, front spoiler top front	M6	7 Nm (5.2 lbf ft)
Screw, front spoiler, right, on footrest bracket	M6	7 Nm (5.2 lbf ft)
Screw, fuel pump	M6	10 Nm (7.4 lbf ft)
Screw, fuel tank attachment, lateral, on frame	M6	11 Nm (8.1 lbf ft)
Screw, ground cable, on frame	M6	7 Nm (5.2 lbf ft)
Screw, handlebar stub	M6	8 Nm (5.9 lbf ft)
		<b>Loctite®243™</b>

## 23 TECHNICAL SPECIFICATIONS

Screw, handlebar weight	M6	9 Nm (6.6 lbf ft)	
Screw, license plate holder on license plate bracket	M6	7 Nm (5.2 lbf ft)	
Screw, magnetic holder on side stand	M6	5 Nm (3.7 lbf ft)	<b>Loctite®243™</b>
Screw, passenger seat	M6	7 Nm (5.2 lbf ft)	
Screw, protective plate	M6	8 Nm (5.9 lbf ft)	
Screw, radiator holder	M6	6 Nm (4.4 lbf ft)	
Screw, rear fender	M6	7 Nm (5.2 lbf ft)	
Screw, shock absorber adjusting ring	M6	3.5 Nm (2.58 lbf ft)	
Screw, side cover	M6	7 Nm (5.2 lbf ft)	
Screw, side cover on front fairing	M6	6 Nm (4.4 lbf ft)	
Screw, side cover retaining bracket	M6	7 Nm (5.2 lbf ft)	
Screw, voltage regulator	M6	11 Nm (8.1 lbf ft)	
Screw, wheel speed sensor holder	M6	8 Nm (5.9 lbf ft)	
Screw, windshield	M6	9 Nm (6.6 lbf ft)	
Nut, rear sprocket screw	M8	38 Nm (28 lbf ft)	
Remaining nuts, chassis	M8	30 Nm (22.1 lbf ft)	
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	
Screw, bottom triple clamp	M8	15 Nm (11.1 lbf ft)	
Screw, connecting plate, subframe	M8	19 Nm (14 lbf ft)	
Screw, foot brake lever	M8	16 Nm (11.8 lbf ft)	<b>Loctite®243™</b>
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	
Screw, fuel tank attachment, front, on frame	M8	20 Nm (14.8 lbf ft)	
Screw, handlebar clamp	M8	15 Nm (11.1 lbf ft)	
Screw, horn	M8	7 Nm (5.2 lbf ft)	
Screw, main silencer	M8	24 Nm (17.7 lbf ft)	
Screw, mirror holder	M8	19 Nm (14 lbf ft)	
Screw, passenger footrest unit	M8	20 Nm (14.8 lbf ft)	<b>Loctite®243™</b>
Screw, presilencer on frame	M8	24 Nm (17.7 lbf ft)	
Screw, rear brake disc	M8	29 Nm (21.4 lbf ft)	<b>Loctite®243™</b>
Screw, retaining bracket on fuel tank	M8	13 Nm (9.6 lbf ft)	
Screw, shift lever	M8	16 Nm (11.8 lbf ft)	<b>Loctite®243™</b>
Screw, subframe bottom	M8	25 Nm (18.4 lbf ft)	<b>Loctite®243™</b>
Screw, top triple clamp	M8	15 Nm (11.1 lbf ft)	
Screw, front brake caliper	M8x1	32 Nm (23.6 lbf ft)	<b>Loctite®243™</b>
Banjo bolt, brake line	M10	24 Nm (17.7 lbf ft)	
Nut, engine bearer, front	M10	48 Nm (35.4 lbf ft)	<b>Loctite®243™</b>

Remaining nuts, chassis	M10	50 Nm (36.9 lbf ft)
Remaining screws, chassis	M10	46 Nm (33.9 lbf ft)
Screw, side stand	M10	35 Nm (25.8 lbf ft) <b>Loctite®243™</b>
Screw, side stand pivot	M10	35 Nm (25.8 lbf ft)
Nut, side stand bracket	M10x1.25	36 Nm (26.6 lbf ft) <b>Loctite®243™</b>
Screw, bottom shock absorber	M10x1.25	50 Nm (36.9 lbf ft) <b>Loctite®243™</b>
Screw, front footrest bracket	M10x1.25	45 Nm (33.2 lbf ft) <b>Loctite®243™</b>
Screw, top shock absorber	M10x1.25	50 Nm (36.9 lbf ft) <b>Loctite®243™</b>
Swingarm pivot	M14	100 Nm (73.8 lbf ft)
Nut, fork pivot	M14x1.5	100 Nm (73.8 lbf ft)
Nut, rear wheel spindle	M14x1.5	100 Nm (73.8 lbf ft)
Screw, steering head, top	M16x1.5	47 Nm (34.7 lbf ft) <b>Loctite®243™</b>
Lambda sensor	M18x1.5	19 Nm (14 lbf ft)
Screw, subframe top	M22	120 Nm (88.5 lbf ft)
Adjusting ring, link fork bearing	M22x1	Tighten and ensure that there is no play
Screw, front wheel spindle	M24x1.5	45 Nm (33.2 lbf ft)
Nut, steering head	M30x1	1. 55 Nm (40.6 lbf ft) 2. Loosen (counterclockwise) 2 turns 3. 5 Nm (3.7 lbf ft)

## 24.1 Declarations of conformity



### Info

The functional and equipment scope is model-dependent and may not include all wireless systems and application areas referred to.

### 210M1100

FCC ID: 2AKR7-210M1100

IC: 22291-210M1100

### BT-ROUTER

FCC ID: Z64-2564N

IC: 4511-2564N

### Declaration regarding modifications

Alterations and modifications not expressly approved by the relevant authority may result in the user being prohibited from operating the equipment.

### Declaration regarding interference

This device fulfills Part 15 of the FCC regulations as well as the license-free RSS standards of the Canadian Government Department **Industry Canada**.

Operation is subject to the following two conditions:

- 1 This device must not cause interference.
- 2 This device must be able to absorb any interference, including interference that potentially causes undesirable operation of the device.

### Note on radio transmissions

This device corresponds to the FCC limit values for radiation exposure, which have been determined for a non-controlled environment, and fulfills the FCC guidelines for the load from radio frequencies.

The transmitter must not be set up near to other antennas or transmitters or operated in conjunction with other antennas or transmitters.

### Note on digital devices of Class B according to the FCC regulations

This device has been tested and fulfills the limit values for digital devices of Class B according to the FCC regulations, Part 15.

These limit values are designed so as to provide sufficient protection from harmful interference in residential areas.

Devices of this type generate and use high frequencies and can also emit these. Therefore, if they are not installed and operated in accordance with the instructions, they may cause harmful interference to radio reception. However, the manufacturer does not guarantee that interference will not occur in certain cases of application.

Should this device cause harmful interference to radio or television reception, (check this by switching the device on and off), you can potentially eliminate this interference as follows:

- Re-align the receiving antenna.
- Increase the separation between device and radio receiver.
- Connect the device and the radio receiver to separate electric circuits.
- Consult your dealer or a radio/TV technician.

### CAN ICES-3 (B) / NMB-3 (B)

This digital device of Class B fulfills the regulations in accordance with the Canadian Interference-Causing Equipment Standard ICES-003 / NMB-003.

**Brake fluid DOT 4 / DOT 5.1****Standard/classification**

- DOT

**Guideline**

- Use only brake fluid that complies with the specified standard (see specifications on the container) and that exhibits the corresponding properties.

**Recommended supplier****Castrol**

- REACT PERFORMANCE DOT 4

**MOTOREX®**

- Brake Fluid DOT 5.1

**Coolant****Guideline**

- Only use high-grade, silicate-free coolant with corrosion inhibitor additive for aluminum motors. Low grade and unsuitable antifreeze causes corrosion, deposits and frothing.
- Do not use pure water as only coolant is able to meet the requirements needed in terms of corrosion protection and lubrication properties.
- Only use coolant that complies with the requirements stated (see specifications on the container) and that has the relevant properties.

Antifreeze protection to at least	-25 °C (-13 °F)
-----------------------------------	-----------------

The mixture ratio must be adjusted to the necessary antifreeze protection. Use distilled water if the coolant needs to be diluted.

The use of premixed coolant is recommended.

Observe the coolant manufacturer specifications for antifreeze protection, dilution and miscibility (compatibility) with other coolants.

**Recommended supplier****MOTOREX®**

- COOLANT M3.0

**Engine oil (SAE 15W/50)****Standard/classification**

- JASO T903 MA2 (📖 p. 124)
- SAE (📖 p. 124) (SAE 15W/50)

**Guideline**

- Use only engine oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Partially synthetic engine oil
--------------------------------

**Recommended supplier****MOTOREX®**

- Formula 4T

## Fork oil (SAE 5)

### Standard/classification

- SAE (📖 p. 124) (SAE 5)

### Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

### Recommended supplier

**MOTOREX®**

- Racing Fork Oil

## Shock absorber fluid (SAE 2.5) (50180751S1)

### Standard/classification

- SAE (📖 p. 124) (SAE 2.5)

### Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

## Super unleaded (ROZ 95)

### Standard/classification

- DIN EN 228 (ROZ 95)

### Guideline

- Only use super unleaded fuel that matches or is equivalent to the specified standard.
- Fuel with an ethanol content of up to 10% (E10 fuel) is safe to use.



### Info

Do **not** use fuel containing methanol (e.g., M15, M85, M100) or more than 10% ethanol (e.g., E15, E25, E85, E100).

---

**Chain cleaner**

Recommended supplier

MOTOREX®

- Chain Clean

**Fuel additive**

Recommended supplier

MOTOREX®

- Fuel Stabilizer

**Long-life grease**

Recommended supplier

MOTOREX®

- Bike Grease 2000

**Motorcycle cleaner**

Recommended supplier

MOTOREX®

- Moto Clean

**Preserving materials for paints, metal and rubber**

Recommended supplier

MOTOREX®

- Moto Protect

**Shine spray for paint, plastic and chromium**

Recommended supplier

MOTOREX®

- Moto Shine

**Special cleaner for glossy and matte paint finishes, metal and plastic surfaces**

Recommended supplier

MOTOREX®

- Quick Cleaner

**Street chain spray**

Guideline

Recommended supplier

MOTOREX®

- Chainlube Road Strong

**Universal oil spray**

Recommended supplier

MOTOREX®

- Joker 440 Synthetic

### **JASO T903 MA2**

Different technical development directions required a separate specification for motorcycles – the **JASO T903 MA2** standard.

Earlier, engine oils from the automobile industry were used for motorcycles because there was no separate motorcycle specification.

Whereas long service intervals are demanded for automobile engines, the focus for motorcycle engines is on high performance at high engine speeds.

In most motorcycle engines, the transmission and clutch are lubricated with the same oil.

The **JASO T903 MA2** standard meets these special requirements.

### **SAE**

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.


ABS	Anti-lock braking system	Safety system that prevents locking of the wheels when driving straight ahead without the influence of lateral forces
-	KTM MY RIDE	System for wireless communication with suitable cell-phones and communication systems for telephony and audio
OBD	On-board diagnosis	Vehicle system, which monitors the specified parameters of the vehicle electronics
-	QUICKSHIFTER+	Engine tuning function for shifting up and down without clutch actuation

## 29 LIST OF ABBREVIATIONS

Art. no.	Article number
ca.	circa
cf.	compare
e.g.	for example
etc.	et cetera
i.a.	inter alia
no.	number
poss.	possibly





### 30.1 Red symbols

Red symbols indicate an error condition that requires immediate intervention.

	The oil pressure warning lamp lights up red – The oil pressure is too low. Stop immediately, taking care not to endanger yourself or other road users in the process, and switch off the engine.
---	--




### 30.2 Yellow and orange symbols

Yellow and orange symbols indicate an error condition that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	The malfunction indicator lamp lights up yellow – The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized KTM workshop.
	The ABS warning lamp lights up yellow – Status or error messages relating to ABS.
	TC indicator lamp lights up yellow – <b>MTC</b> is not enabled or is currently intervening. The TC indicator lamp also lights up if a malfunction is detected. Contact an authorized KTM workshop. The TC indicator lamp flashes if <b>MTC</b> makes an active intervention.
	The general warning lamp lights up yellow – A note/warning note on operating safety has been detected. This is shown in addition.

### 30.3 Green and blue symbols

Green and blue symbols reflect information.

	The turn signal indicator lamp flashes green simultaneously with the turn signal – The turn signal is switched on.
	The idle indicator lamp lights up green – The transmission is in the neutral position.
	The high beam indicator lamp lights up blue – The high beam is switched on.

<b>1</b>	
<b>12-V battery</b>	
installing . . . . .	86
removing . . . . .	86
<b>12-V battery</b>	
charging . . . . .	87
<b>A</b>	
<b>ABS</b> . . . . .	72
<b>ABS fuses</b>	
changing . . . . .	89
<b>ACC1</b>	
front . . . . .	93
rear . . . . .	93
<b>ACC2</b>	
rear . . . . .	93
<b>Antifreeze</b>	
checking . . . . .	95
<b>Anti-lock braking system</b> . . . . .	72
<b>Auxiliary substances</b> . . . . .	12
<b>B</b>	
<b>Brake discs</b>	
checking . . . . .	73
<b>Brake fluid</b>	
front brake, adding . . . . .	74
rear brake, adding . . . . .	76
<b>Brake fluid level</b>	
front brake, checking . . . . .	73
of the rear brake, checking . . . . .	76
<b>Brake lining retainers</b>	
of front brake, checking . . . . .	75
of rear brake, checking . . . . .	78
<b>Brake linings</b>	
of front brake, checking . . . . .	75
of rear brake, checking . . . . .	78
<b>Brakes</b> . . . . .	52
<b>Braking</b> . . . . .	52
<b>Breakdown</b>	
towing . . . . .	55
<b>C</b>	
<b>Capacity</b>	
coolant . . . . .	114
engine oil . . . . .	114
Fuel . . . . .	56, 114
<b>Chain</b>	
chain dirt accumulation, checking . . . . .	64
checking . . . . .	66
cleaning . . . . .	64
<b>Chain tension</b>	
adjusting . . . . .	65
checking . . . . .	65
<b>Clutch lever</b> . . . . .	17
basic position, adjusting . . . . .	24
<b>Combination instrument</b>	
<b>ABS</b> . . . . .	39
<b>ABS display</b> . . . . .	29
activation and test . . . . .	26
<b>Audio</b> . . . . .	37
<b>Bluetooth</b> (optional) . . . . .	42
coolant temperature indicator . . . . .	31
day-night mode . . . . .	26
display . . . . .	28
<b>Display Theme</b> . . . . .	42
<b>Distance</b> . . . . .	44
engine speed . . . . .	29
<b>Extra Functions</b> . . . . .	45
<b>Favourites</b> . . . . .	41
<b>Favourites display</b> . . . . .	32
fuel level display . . . . .	31
<b>Fuel Cons</b> . . . . .	44
<b>General Info</b> . . . . .	38
<b>Headset</b> . . . . .	36
indicator lamps . . . . .	27
<b>KTM MY RIDE</b> . . . . .	33
<b>Language</b> . . . . .	45
menu . . . . .	33
<b>Motorcycle</b> . . . . .	34
<b>MTC display</b> . . . . .	29
<b>MTC+MSR</b> (optional) . . . . .	40
<b>ODO display</b> . . . . .	30
Overview . . . . .	26
<b>Pairing</b> . . . . .	34
<b>Phone</b> . . . . .	35
<b>Quick Selector 1</b> . . . . .	41
<b>Quick Selector 1 display</b> . . . . .	32
<b>Quick Selector 2</b> . . . . .	41
<b>Quick Selector 2 display</b> . . . . .	32
<b>Quick Shift+</b> (optional) . . . . .	41
<b>Service</b> . . . . .	45
<b>Settings</b> . . . . .	34
shift warning light . . . . .	30
speed . . . . .	30
telephony . . . . .	38
Time . . . . .	32
<b>Trip 1</b> . . . . .	38
<b>Trip 2</b> . . . . .	39
<b>Trips/Data</b> . . . . .	33
<b>Warning</b> . . . . .	39
warnings . . . . .	27
<b>Combination switch</b> . . . . .	17
Overview . . . . .	17

<b>Coolant</b>		
draining	.....	96
<b>Coolant level</b>		
checking	.....	95
compensating tank, checking	.....	94
<b>Cooling system</b>	.....	94
filling/bleeding	.....	97
<b>Customer service</b>	.....	12
<b>D</b>		
<b>Date</b>		
adjusting	.....	43
<b>Declarations of conformity</b>	.....	120
<b>Diagnostics connector</b>	.....	93
<b>E</b>		
<b>Emergency OFF switch</b>	.....	19
<b>Engine</b>		
running in	.....	47
<b>Engine number</b>	.....	15
<b>Engine oil</b>		
adding	.....	104
changing	.....	102
<b>Engine oil level</b>		
checking	.....	102
<b>Engine sprocket</b>		
checking	.....	66
<b>Environment</b>	.....	11
<b>F</b>		
<b>Figures</b>	.....	12
<b>Filling up</b>		
fuel	.....	55
<b>Foot brake lever</b>	.....	23
free travel, adjusting	.....	79
free travel, checking	.....	78
<b>Fork</b>		
compression damping, adjusting	.....	59
rebound, adjusting	.....	59
<b>Fork legs</b>		
dust boots, cleaning	.....	62
<b>Front fender</b>		
installing	.....	71
removing	.....	71
<b>Front rider's seat</b>		
mounting	.....	63
removing	.....	63
<b>Front wheel</b>		
installing	.....	80
removing	.....	80
<b>Fuel tank cover</b>		
mounting	.....	68
removing	.....	67
<b>Fuel tank filler cap</b>		
closing	.....	21
opening	.....	20
<b>Fuel, oils, etc.</b>	.....	12
<b>Fuse</b>		
of individual electrical power consumers, changing	.....	91
<b>H</b>		
<b>Hand brake lever</b>	.....	17
basic position, adjusting	.....	24
<b>Handlebar</b>		
on the right side of the handlebar	.....	19
<b>Headlight</b>		
headlight range, adjusting	.....	92
<b>Headlight range</b>		
adjusting	.....	92
<b>Headlight setting</b>		
checking	.....	92
<b>Horn button</b>	.....	18
<b>I</b>		
<b>Ignition lock</b>	.....	19
<b>Implied warranty</b>	.....	12
<b>Indicator lamps</b>	.....	27
<b>Intended use</b>	.....	6
<b>K</b>		
<b>Key number</b>	.....	16
<b>L</b>		
<b>Light switch</b>	.....	18
<b>Load the vehicle</b>	.....	47
<b>Luggage</b>	.....	47
<b>M</b>		
<b>Main fuse</b>		
changing	.....	89
<b>Manufacturer warranty</b>	.....	12
<b>Misuse</b>	.....	6
<b>Motorcycle</b>		
cleaning	.....	105
lifting with front lifting gear	.....	61
rear lifting gear, raising with	.....	61
removing the rear from the lifting gear	.....	61
taking off front lifting gear	.....	62
<b>O</b>		
<b>Oil filter</b>		
changing	.....	102

<b>Oil screens</b>		
cleaning	.....	102
<b>Owner's Manual</b>	.....	11
<b>P</b>		
<b>Parking</b>	.....	53
<b>Passenger foot pegs</b>	.....	22
<b>Play in the clutch lever</b>		
adjusting	.....	101
checking	.....	101
<b>Preparing for use</b>		
advice on preparing for first use	.....	46
after storage	.....	108
checks and maintenance measures when preparing for use	.....	48
<b>Protective clothing</b>	.....	10
<b>Q</b>		
<b>Quickshifter +</b>	.....	50
<b>R</b>		
<b>Rear hub damping rubber pieces</b>		
checking	.....	83
<b>Rear sprocket</b>		
checking	.....	66
<b>Rear wheel</b>		
installing	.....	82
removing	.....	81
<b>Riding</b>	.....	50
starting off	.....	49
<b>S</b>		
<b>Safe operation</b>	.....	10
<b>Seat lock</b>	.....	21
<b>Service</b>	.....	12
<b>Service schedule</b>	.....	57-58
<b>Shift lever</b>	.....	22
adjusting	.....	24
<b>Shifting</b>	.....	50
<b>Shock absorber</b>		
rebound damping, adjusting	.....	60
spring preload, adjusting	.....	60
<b>Side cover, left</b>		
installing	.....	69
removing	.....	69
<b>Side cover, right</b>		
installing	.....	70
removing	.....	70
<b>Side stand</b>	.....	23
<b>Spare parts</b>	.....	12
<b>Start button</b>	.....	19
<b>Starting</b>	.....	48
<b>Steering</b>		
locking	.....	19
unlocking	.....	20
<b>Steering lock</b>	.....	19
<b>Stopping</b>	.....	53
<b>Storage</b>	.....	107
<b>Supporting strap</b>	.....	22
<b>Switch</b>		
on the left side of the handlebar	.....	17
<b>T</b>		
<b>Technical accessories</b>	.....	12
<b>Technical specifications</b>		
capacities	.....	114
chassis	.....	114
chassis tightening torques	.....	116
electrical system	.....	115
engine	.....	111
engine tightening torques	.....	112
fork	.....	115
shock absorber	.....	116
tires	.....	115
<b>Throttle grip</b>	.....	17
<b>Time</b>		
adjusting	.....	43
<b>Tire condition</b>		
checking	.....	84
<b>Tire pressure</b>		
checking	.....	85
<b>Tool set</b>	.....	22
<b>Towing</b>	.....	55
<b>Transport</b>	.....	54
<b>Troubleshooting</b>	.....	109-110
<b>Turn signal switch</b>	.....	18
<b>Type label</b>	.....	15
<b>U</b>		
<b>Use definition</b>	.....	6
<b>V</b>		
<b>Vehicle identification number</b>	.....	15
<b>View of vehicle</b>		
front left	.....	13
rear right	.....	14
<b>W</b>		
<b>Winter operation</b>		
checks and maintenance steps	.....	106
<b>Work rules</b>	.....	11



3214955en

28.02.2024

